

JTT TECH PTE LTD

1 Yishun Industrial Street 1 #04-24 A'POSH BizHub Singapore 768160

Tel: (65) 6262 5887 Fax: (65) 6339 1383

Website: www.jtt.sg Email: jtt@jtt.sg

Company Reg. No: 201701120E GST Reg No.: 20-1701120-E

TEL Clean Track Mark 7 and Mark 8

CARRIER STATION

No.	OEM Part No	Parts Name
1	1985-444265-11	C/S #4 FRAME ASSY
2	1985-419253-11	CASSETTE STAGE ASS'Y
3	1910-110756-13	CASSETTE STAGE 8"
4	1910-110757-12	CASSETTE STAGE 6",8"
5	1985-413376-11	CASSETTE SWITCH (L) ASSY
6	1910-110604-14	SWITCH PLATE
7	1910-422608-11	SENSOR SHAFT L
8	310-492483-1	SPRING ELV
9	1904-300076-11	LEFT END BLOCK
10	1310-496772-11	BROCKET 2
11	1910-420679-12	SENSOR BLOCK
12	1904-400074-11	SHAFT GUIDE
13	044-000044-1	BOARD SUPPORT..EM-3
14	1985-431491-11	C/S 8' CARRIER GUIDE (PA192-80M)
15	1904-300073-11	CASSETTE CENTER GUIDE
16	1904-400035-11	CASSETTE GUIDE 80M R
17	1910-425028-11	CASSETTE GUIDE HL-L
18	1904-400036-11	CASSETTE GUIDE 80M L
19	1910-424142-11	CASSETTE GUIDE 60MB L
20	1910-425029-11	CASSETTE GUIDE HI-R
21	1904-400037-11	CASSETTE GUIDE 80M F-R
22	1910-424143-11	CASSETTE GUIDE 60M F-R
23	1910-424147-11	CARRIER SPACER F,R
24	1910-424106-11	CARRIER SPACER 6",R
25	1985-413379-11	WAF EDGE SENSOR ASSY (2)
26	1910-426312-11	SENSOR BLOCK A-SLIT
27	1910-424791-11	SENSOR BLOCK B-SLIT
28	1986-401447-11	7,8 C/S ELEC. IPL (STAGE)
29	1386-444163-14	WAF EDGE SENSOR LEFT SOURCE
30	1386-444165-15	WAF EDGE SENSOR RECEIVER
31	1386-444848-13	8" CARRIER SENSOR ASSY
32	1386-000863-12	CARRIER STAGE SW.. AB12C-6029/AEO
33	1987-412407-11	C/S ARM X ASSY
34	310-290647-7	PINCETTE
35	1310-290833-13	PINCETTE 8" C/A
36	310-392002-8	P HOLDER
37	1310-392434-14	P HOLDER 6" C/A
38	1910-321310-13	GUIDE L
39	1910-318288-14	GUIDE 6" C/A
40	1910-321311-13	GUIDE R
41	1910-318289-14	GUIDE R 6" C/A
42	1380-101160-11	PULLEY M
43	1380-101161-11	PULLEY 1
44	1380-101162-11	PULLEY 2
45	1380-101163011	PULLEY 3
46	1910-425614-12	SENSOR BLOCK RE
47	1910-421664-11	SENSOR BLOCK 6"-6

48	1380-101170-11	SENSOR BRACKET H-6"/8"
49	1910-423412-11	SENSOR BRACKET C/S-8E
50	1910-423413-11	SENSOR BROCKET C/S-6E
51	024-011644-1	AIR CYLINDER..10S-1 SD12N30-XB
52	024-011602-1	AIR CYLINDER..7Z-1 SD6N60P
53	018-002226-1	LM GUIDE...RSR7ZM+94LMS
54	018-001050-1	LINEAR WAY..LML7C1R270T1H/A
55	018-000949-1	SLIDE BUSH...SMSK6UU
56	023-000585-1	TIMING BELT...550-2GT-6
57	023-000831-1	TIMING BELT...196-2GT-9
58	022-00042-1	BEARING..LF-1260ZZ
59	1987-412408-11	C/S ARM Y ASSY
60	1380-001465-11	PULLEY ASSY(1) ..T326012301
61	1380-001463-11	PULLEY ASSY CS-2..T327-10301
62	023-000832-1	TIMMING BELT...290-2GT-9
63	1380-100601-11	DRIVE BELT...73830X5
64	1380-101486-11	Y HOME SENSOR ... CS/IF
65	1987-412409-11	C/S ARM Z ASSY
66	1380-102358-11	SLIDER..KR-CS-Z-01-3
67	1380-100546-11	BELT..73060X9
68	1380-101485-11	Z HOME SENSOR CS/F
69	1380-101449-11	CN-20 CABLE
70	1380-001206-11	CN23 FLAT CABLE CS
71	1380-001205-11	CN22 FLAT CABLE CS
72	1380-001204-11	CN21 FLAT CABLE CS
73	1380-001203-11	CN10 FLAT CABLE CS
74	1380-001202-11	CN9 FLAT CABLE CS
75	1380-001201-11	CN8 FLAT CABLE CS
76	1380-001200-11	CN7FLAT CABLE CS
77	1380-101446-11	LIN21 CABLE
78	1380-101443-11	MECHATRO CABEL ASST
79	1986-4013340-11	C/S ARM ELECTRICE ASSY
80	1380-001207-11	NET TUBE..CN-Z CS
81	1380-001208-11	NET TUBE..Z-X CS
82	1987-412411-11	C/SARM DRIVER ASSY
83	1380-101451-12	Z AXIS DRIVER..MSD5A1A1XX
84	1380-101452-12	Y AXIS DRIVER..MSD5A1A1XX
85	1380-101447-11	LIN22 CABLE
86	1380-101441-11	CN-4 CABLE
87	1380-101448-11	LIN23 CABLE
88	1380-101445-11	LIN18 CABLE
89	1380-101242-11	CN-5 CABLE
90	1380-101442-11	CN-6 CABLE
91	1380-101444-11	LIN4/LIN5 CABLE
92	1386-444896-11	SERVO DRIVER AC CABLE #1
93	1985-429686-11	SMIF FRAME (3IND)
94	1987-412989-11	SMIF ARM IPL X AXIS ASSY
95	1910-111533-14	X BASE
96	1910-432595-11	PIN HOLD BASE
97	1910-432596-11	LEFT PIN HOLDER
98	1910-432597-11	RIGHT PIN HOLDER
99	310-496308-1	SHAFT P
100	1910-432598-11	PIN SHUTTER
101	1910-432599-11	PIN SENSOR BROCKET
102	1910-418355-13	AD PIN-S

103	1910-432600-12	CYLINDER JOINT
104	1910-432601-12	PINCETTE BASE
105	1910-432602-11	PINCETTE BASE HOLD
106	1910-432603-12	HOLD BASE
107	1910-432606-11	GUIDE HOLD
108	1910-432605-11	X SHUTTER
109	1310-496527-13	BELT BLOCK A
110	1310-496528-12	BELT BLOCK B
111	1910-426514-11	TENSION SHAFT
112	1910-426515-12	TENSION HOUSING
113	1910-433816-12	X MOTOR BASE
114	310-491379-1	MOTOR SPACER
115	1910-428132-11	M3 SCREW
116	1902-411263-11	MOTOR PULLEY
117	1910-432613-12	SEPARATION COVER
118	1910-327869-11	LEFT SIDE COVER
119	1901-327870-11	RIGHT SIDE COVER
120	1910-432607-11	RIGHT WIRING COVER
121	1910-327865-11	FR UPPER COVER
122	1910-327866-12	FR UNDER COVER
123	19100-327867-12	REAR UPPER COVER
124	1910-327868-11	REAR UNDER COVER
125	022-0000345-1	BEARING..688ZZS
126	044-001075-1	SUBSTRATE..SA6-40
127	044-001058-1	SUBSTRATE..SA6-20
128	044-000131-1	SUBSTRATE..TA305
129	044-000135-1	SUBSTRATE..TB-300
130	018-001081-1	SLIDE BUSH...SMK6G-SK-1
131	023-001138-1	TIMING BELT..B60S3M804G
132	024-003315-1	SPEED CONTROLLER...AS1201F-M5-04
133	024-012614-1	AIR CYLINDER...CQ2A12-30D-XB9
134	026-001300-1	GROMMET..G-110-7210
135	018-001453-1	LM GUIDE...HSR10R1UUC1M+345LHM
136	1909-413897-11	ARM SEAL
137	021-100309-1	E RING
138	19850456773-11	SMIF ARM X PULLEY ASSY
139	1910-451737-11	FRONT SENSOR BROCKET
140	1386-458644-11	SMIF ARM X HOME SENSOR ASSY
141	1386-458645-11	SMIF ARM 4PIN UP SENSOR ASSY
142	1386-458646-11	SMIF ARM 4PIN DOWN SENSOR ASSY
143	1386-458642-12	SMIF ARM WAFER SENSOR ASSY
144	1381-658279-11	SMIF ARM CONN C BOARD
145	1386-458641-11	SMIF ARM MOTOR ASSY
146	1985-431594-11	SMIF C/A 8" CONVERSION
147	310-290647-7	PINCETTE
148	310-392002-8	P HOLDER
149	1910-321310-13	GUIDE L
150	1910-321311-13	GUIDE R
151	1910-425614-12	SENSOR BLOCK RE
152	1910-425613-12	SENSOR BLOCK SE
153	1987-412991-11	SMIF ARM IPL Y COMMON ASSY
154	310-496440-1	F.C HOLDER
155	310-496443-6	BLOCK B
156	1310-497013-11	CABLE COVER
157	1310-392469-11	BOARD COVER

158	1910-432708-13	Y SENSOR BRACKET
159	310-496439-1	ADJUSTMENT BLOCK A
160	1910-320928-13	MOTOR BRACKET
161	302-490105-1	PULLEY
162	023-000055-1	TIMING BELT..345-3GT-15
163	310-496445-2	STOPPER BLOCK
164	310-392105-6	BLOCK A
165	310-496447-1	BELT BLOCK
166	310-496448-1	BRACKET
167	310-496449-1	ADJUSTMENT BLOCK B
168	310-392099-5	SIDE PLATE C
169	310-392100-5	SIDE PLATE D
170	1910-433220-12	ARM CORNER BLOCK
171	1910-426973-11	TUBE HOLDER
172	026-001329-1	MAGNET CATCH
173	047-000627-1	DUCT PARTS..TKP0180-2B PIA MOVING BRACKET
174	047-000628-1	DUCT PARTS..TKP0180-2B PIA MOVING BRACKET
175	044-000131-1	SUBSTRATE SUPPORT..TA--305
176	044-000135-1	SUBSTRATE SUPPORT..TB--300
177	1985-433853-11	M/A Y IDLER PULLEY ASSY
178	1985-433854-11	M/A Y DRIVER PULLEY ASSY
179	1386-458628-12	SMIF ARM Y MOTOR ASSY
180	1386-458670-11	SMIF ARM A SIGNAL EXT.CABLE
181	1386-458671-12	SMIF ARM A DC EXT.CABLE
182	1386-458672-12	SMIF ARM STEP MOTOR EXT.CABLE
183	1386-458673-11	SMIF ARM STEP MOTOR ENC..EXT.CABLE
184	1386-458674-12	SMIF ARM Y MOTOR DRIVE EXT..CABLE
185	1386-458675-11	SMIF ARM Y MOTOR ENC EXT.CABLE
186	1386-458676-12	SMIF ARM Z MOTOR DRIVE EXT..CABLE
187	1386-458677-11	SMIF ARM Z MOTOR ENC.EXT.CABLE
188	1987-412992-11	SMIF ARM IPL Y6 ASSY
189	1310-290795-14	SIDE PLATE A6
190	1310-290796-12	SIDE PLATE B6
191	018-000435-1	LINEAR WAY..LWHS15C1R900B-LR
192	018-000434-1	LINEAR WAY..LWHS15C2R1080-LR
193	023-000316-1	TIMING BELT..2050-5GT-15 OPEN
194	1310-392394-13	COVER 6
195	026-001328-1	MAGNET CATCH..TL-272-2-1787
196	1310-392472-12	CHAIN SUPPORT A6
197	1310-392477-13	CHAIN SUPPORT B6
198	047-000457-1	FLEXIBLE DUCT..TKP0180-2BR37-30L
199	1381-658277-11	SMIF ARM CONN A BOARD
200	1386-458629-12	SMIF ARM FLEX CABLE
201	1386-458630-11	SMIF ARM Y HOME SENSOR ASSY
202	1987-412990-11	SMIF ARM IPL ZR AXIS ASSY
203	1310-290804-16	THET A BASE
204	1903-200047-13	Z BASE M (200W PA)
205	1910-216393-11	Z UPPER BASE
206	310-490036-3	BLOCK B
207	310-4900038-1	SHAFT B
208	310-496113-2	COVER BRACKET
209	1910-432469-11	WIRING PIPE
210	1910-432640-11	Z MOUNT BASE
211	1910-452925-11	Z AXIS SHUTTER
212	310-490049-1	BEARING HOLDERC

213	1310-496503-13	COVER A
214	1310-496504-12	COVER B
215	1910-432470-12	FR REAR COVER
216	1910-432471-11	Z SIDE COVER
217	1910-435418-11	Y AXIS SHUTTER
218	1310-496509-12	PIPE HOLDER
219	1310-496510-11	STOPPER
220	1902-411174-11	Z AXIS SHAFT
221	1910-451740-11	BOARD BRACKET
222	1910-432472-11	FAN SIDE COVER
223	1310-496512-11	B FIXING WASHER
224	019-000156-1	BALL SCREW..W1504-267-C7S10
225	018-000199-1	CROSS ROLLER RING..RA18013UUCO
226	022-100133-1	BEARING..R-2280ZZ
227	022-000163-1	BEARING..SSR-1960ZZ
228	018-001086-1	SLIDE BUSH..SMK16WUU-SK
229	022-000018-1	BEARING PARTS..FU00SUS FINE U NUT
230	1902-411202-11	Z PULLEY
231	1902-411206-12	MOTOR PULLEY
232	1310-496513-12	HOUSING
233	1310-496514-13	BEARING HOLDER
234	1310-496515-12	COLLAR
235	1310-497089-11	PIPE END
236	022-100408-1	BEARING..7000CTDFC8P5
237	1910-432473-14	X EXH DUCT
238	1310-496603-13	GUIDE PIN
239	1903-300044-12	JOINT BLOCK
240	1310-496520-11	SENSOR BRACKET
241	028-003338-1	TUBE JOINT..M-5HL-4
242	028-003339-1	TUBE JOINT..M-5HL-6
243	1910-432671-11	SOL BRACKET
244	1910-329709-11	WIRING BRACKET
245	1910-422762-11	WIRING COVER
246	1910-432704-11	CHAIN MOUN T
247	1910-429008-14	FC BRACKET (VAC)
248	1310-497011-13	F.C HOLDER
249	1310-392470-15	BOARD BRACKET
250	1910-451742-11	CENTER COVER
251	1310-497090-12	THETA STOPPER
252	1910-432474-11	Z DUCT PACKING
253	028-006348-1	TUBE JOINT..EYB4-4-NI
254	044-000131-1	SDUBSTRATE SUPPORT..TA-305
255	044-000135-1	SDUBSTRATE SUPPORT..TB-300
256	012-004049-1	SOLENOID VALVE..VJ3143Y-6M0ZB-M5
257	1910-435419-11	SHUTTER BASE
258	1902-411191-11	PULLEY
259	023-001280-1	TIMING BELT..687-3GT-8
260	023-001290-1	TIMING BELT..B150S3M207G
261	1910-437809-11	R AXIS BRACKET
262	1910-437808-12	R AXIS SHUTTER
263	1910-437810-12	BELT HOLDER
264	1910-437811-12	BELT ROLL BLOCK
265	1910-448465-11	Z WIRING COVER
266	1910-349416-11	Z EXH DUCT
267	1386-458632-11	SMIF ARM THETA MOTOR ASSY

268	1386-458633-11	SMIF ARM THETA HOME SENSOR..ASSY
269	1386-458634-11	SMIF ARM 4PIN UP SOLENOID ASSY
270	1381-658278-11	SMIF ARM CONN B BOARD
271	1386-458636-12	SMIF ARM Z MOTOR EXT.CABLE
272	1386-458637-11	SMIF ARM Z ENC.EXT.CABLE
273	1386-458638-11	SMIF ARM X MOTOR EXT.CABLE
274	1386-458639-11	SMIF ARM X ENC.EXT.CABLE
275	1386-458640-11	SMIF ARM C SIGNAL CABLE
276	1386-458631-11	SMIF ARM Z MOTOR ASSY
277	1386-458647-11	SMIF ARM DC FAN ASSY (1)
278	1386-458648-11	SMIF ARM DC FAN ASSY (2)
279	1386-461392-11	SMIF ARM DC FAN EXT CABLE
280	1386-458643-11	SMIF ARM Z HOME SENSOR ASSY
281	1910-356126-11	Z BOTTOM BASE
282	1910-452956-11	Z SIDE COVER
283	1987-412993-11	SMIF ARM IPL DRIVER BOX ASSY
284	1910-111622-12	DRIVER CASE
285	1910-328748-12	CASE COVER
286	1910-328749-13	CONNECTOR BRACKET
287	1910-433366-11	DRIVER BRACKET
288	044-000131-1	SUBSTRATE SUPPORT..TZ-305
289	044-000135-1	SUBSTRATE SUPPORT..TB-300
290	1910-427900-11	DRIVER SPACER
291	044-001047-1	SUBSTRATE SUPPORT..SA6-10
292	040-570216-1	MOTOR DRIVER..PMM-BD-5702-4
293	040-001777-1	MOROR DRIVER..MSD011A1XX
294	1381-658276-11	SMIF ARM DRIVER I/F BOARD
295	1386-458651-11	SMIF ARM Y DRIVER SIGNAL CABLE
296	1386-458652-12	SMIF ARM Y MOTOR DRIVE CABLE
297	1386-458653-11	SMIF ARM Y MOTOR ENC.CABLE
298	1386-458654-11	SMIF ARM Z DRIVER SIGNAL CABLE
299	1386-458655-12	SMIF ARM Z MOTOR DRIVE..HARNES
300	1386-458656-11	SMIF ARM Z MOTOR ENC.CABLE
301	1386-458658-11	SMIF ARM X DRIVE SIGNAL CABLE
302	1386-458659-11	SMIF ARM THETA DRIVE SIGNAL..CABLE
303	1386-458662-11	SMIF ARM A SIGNAL CABLE
304	1386-458663-11	SMIF ARM A DC CABLE
305	1386-458660-11	SMIF ARM STEP MOTOR DRIVE..HARNES
306	1386-458661-11	SMIF ARM STEP MOTOR ENC.CABLE
307	1386-458657-11	SMIF ARM DRIVER AC CONN CABLE
308	1987-413302-1*	SMIF INDEXER IPL 8200 ASSY
309	1380-101692-11	IND BASE..AM147-2-1
310	1380-101693-12	OUTSIDE PLATE..AM147-2-2
311	1380-101694-12	INSIDE PLATE..AM147-2-3B
312	1380-101695-11	CORNER GUIDE..AM147-2-4
313	1380-101696-11	RIGHT REAR GUIDE..AM147-2-5A
314	1380-101697-11	LEFT FR GUIDE..AM147-2-5B
315	1380-101698-12	PUSH PLATE BASE..AM147-2-6A
316	1380-101699-11	PUSH PLATE..AM147-2-6B
317	1380-101700-11	PUSH ARM..AM147-2-7
318	1380-101701-11	PUSH CYLINDER BRACKET..AM147-2-8
319	1380-101702-12	LEFT SENSOR BRACKER..AM147-2-9
320	1380-101703-12	RIGHT SENSOR BRACKET..AM147-2-10
321	1380-101714-11	IND STOPPER..AM147-2-11
322	1380-101705-12	LOCK BLOCK..AM147-2-12

323	1380-1-1706-11	CYLINDER JOINT..AM147-2-13
324	1380-101707-11	BLOCK JOINT..AM147-2-14
325	1380-101708-11	ARM JOINT..AM147-2-15
326	1380-101709-11	SENSOR HOLDER..AM147-2-17
327	1380-101710-11	POSITION PIN..AM147-2-18
328	1380-102542-11	PIN BASE..AM1472-19B
329	1380-101712-11	INNER HOLDER..AM147-2-20
330	1380-102541-11	ROTARY PIN..AM147-2-21
331	1380-101714-11	CYLINDER OUT STOPPER..AM147-2-23
332	1380-101715-11	OUTER HOLDER..AM147-2-24
333	1380-101716-11	CYLINDER IN STOPPER..AM147-2-25
334	1380-101717-11	SENSOR SHAFT..AM147-2-26
335	1380-101718-11	CONTR BRACKET..AM147-2-27
336	1380-101719-11	SENSOR HOLDER..AM147-2-28
337	1380-101720-11	SHAFT GUIDE..AM147-2-29
338	1380-101721-12	SLIDE BLOCK..AM147-2-30B
339	1380-101722-11	CYLINDER JOINT BLOCK..AM147-2-31
340	1380-101723-12	LEFT REAR SUPPORT..AM147-2-32A
341	1380-101724-12	RIGHT REAR SUPPORT..AM147-2-32A
342	1380-101725-12	RIGHT FR SUPPORT..AM147-2-32B
343	1380-101726-12	LEFT FR SUPPORT..AM147-2-32B
344	1380-101727-11	LEFT OUTSIDE COVER..AM147-2-33A
345	1380-101728-11	RIGHT OUTSIDE COVER..AM147-2-33B
346	1380-101729-12	LEFT TOP COVER..AM147-2-34A
347	1380-101730-11	LEFT UNDER COVER..AM147-2-34B
348	1380-101731-11	RIGHT TOP COVER..AM147-2-35A
349	1380-101732-11	RIGHT UNDER COVER..AM147-2-35B
350	1380-101733-11	RIGHT FOOT..AM147-2-36A
351	1380-101734-11	LEFT FOOT..AM147-2-36B
352	1380-101735-11	MOTORBASE..AM147-2-37
353	1380-101736-11	IND BOTTOM BASE..AM147-2-38A
354	1380-101737-11	TENSION ADJUSTABLE PLATE..AM147-2-38B
355	1380-101738-11	SECONDARY PULLEY..AM147-2-39
356	1380-101739-11	PRIMARY PULLEY..AM147-2-40
357	1380-101740-11	UNDER RIGHT PLATE..AM147-2-41
358	1380-101741-12	UNDER LEFT PLATE..AM147-2-42
359	1380-101742-11	UNDER BACK PLATE..AM147-2-43
360	1380-101743-11	BALL SCREW..AM147-2-44
361	1380-101744-12	NUT BLOCK..AM147-2-45
362	1380-101745-11	SHUTTER..AM147-2-46
363	1380-101746-11	TOP FR PLATE..AM147-2-47
364	1380-101747-11	TOP FR PLATE..AM147-2-48
365	1380-101748-12	TOP BRACKET ..AM147-2-49A
366	1380-102072-11	MIDDLE BRACKET..AM147-2-49B
367	1380-102073-11	BOTTOM BRACKET..AM147-2-39C
368	1380-102074-11	NUT PLATE..AM147-2-49D
369	1380-101749-11	TOP DUCT SUPPORT..AM149-2-50
370	1380-101750-11	UNDER DUCT SUPPORT..AM147-2-51
371	1380-101751-12	UNDER FR COVER..AM147-2-52
372	1380-101752-11	LEFT PLATE GUIDE..AM147-2-53A
373	1380-101753-11	RIGHT PLATE SUPPORT..AM147-2-53B
374	1380-101754-12	PLATE SUPPORT BASE..AM147-2-54
375	1380-101755-12	CONTR BRACKET..AM147-2-55
376	1380-102546-11	PIN..AM147-2-18B
377	024-012921-1	OIL PRESSURE CYLINDER..CDJ2B6-60R-B-XB9

378	024-012022-2	OIL PRESSURE CYLINDER..CDU6-25D-XB9
379	024-012923-1	OIL PRESSURE CYLINDER..CDU25-50D-XB9
380	018-001080-1	SLIDE PACK..ER616+70L
381	018-001039-1	SLIDE PACK..ER616+95L
382	018-001637-1	LM GUIDE..RSR12VMUU+120LM
383	108-001638-1	LM GUIDE..HSR12RUUC1M+350LM-1
384	024-012924-1	SPEED CONTROLLER..SC-M5-A
385	024-002507-1	SPEED CONTROLLER..SC-M5-S
386	022-000119-1	BEARING..6809ZZ
387	025-100299-1	SPRING..10180
388	019-000183-1	BALL SCREW PARTS..BUK-12A SUPPORT UNIT
389	1380-101762-11	VALVE,SOL..VV5J3-32-03-X624
390	028-002836-1	TUBE JOINT..KJS04-M5
391	028-002837-1	TUBE JOINT..KJU04-00
392	020-001720-1	FIXING SCREW..PT1/8 SUS TAPER PLUG 1KINDS
393	028-004347-1	TUBE JOINT..KJL06-01S
394	028-003337-1	TUBE JOINT..M-5H-4
395	028-003338-1	TUBE JOINT..M-5HL-4
396	028-002956-1	TUBE JOINT..M-5J
397	023-001291-1	TIMING BELT..340-2GT-9
398	021-100262-1	E RING..ETW-4 SUS304
399	026-003155-1	POSITIONING BOLT..SANB6-20
400	026-002437-1	POSITIONING PIN..STEH10
401	047-001273-1	FLEXIBLE DUCT..TKP0130-1BR37-36L
402	047-001274-1	FLEXIBLE DUCT PARTS..TKP0130-1B PKA FIXING BRACKET
403	047-001275-1	FLEXIBLE DUCT PARTS..TKP0130-1B PIA MOVING BRACKET
404	018-001444-1	CAM FOLLOWER..CF3M-A
405	044-001046-1	SUBSTRATE SUPPORT..SB6-10
406	044000045-1	SUBSTRATE SUPPORT..EM-5
407	1380-101545-11	SMIF INDEXER CONN.BOARD
408	1380-101772-11	POD SENSOR ASSY
409	1380-101773-11	HOME SENSOR ASSY
410	1380-101774-11	UP LIMIT SENSOR ASSY
411	1380-101776-11	MAP SENSOR ASSY
412	1380-101777-11	WAF SENSOR (HORIZON) ASSY
413	1380-101778-11	WAF SENSOR (VERTICAL) ASSY (TX)
414	1380-101779-11	WAF SENSOR (VERTICAL) ASSY (RX)
415	1380-101781-11	POD LOCK1 SENSOR EXT.CABLE
416	1380-101782-11	POD LOCK1 SENSOR ASSY
417	1380-101783-11	POD LOCK2 SENSOR EXT.CABLE
418	1380-101784-11	POD LOCK2 SENSOR ASSY
419	1380-101785-11	POD UNLOCK1 SENSOR EXT.CABLE
420	1380-101786-11	POD UNLOCK1 SENSOR ASSY
421	1380-101787-11	POD UNLOCK2 SENSOR EXT.CABLE
422	1380-101788-11	POD UNLOCK2 SENSOR ASSY
423	1380-101789-11	POD DOOR OPEN SENSOR EXT.CABLE
424	1380-101790-11	PLD DOOR OPEN SENSOR ASSY
425	1380-101791-11	POD DOOR CLOSE SENSOR..EXT.CABLE
426	1380-101792-11	POD DOOR CLOSE SENSOR ASSY
427	1380-101793-11	WAF PUSH ARM IN SENSOR CABLE
428	1380-101794-11	WAF PUSH ARM IN SENSOR ASSY
429	1380-101795-11	WAF PUSH ARM OUT SENSOR CABLE
430	1380-101796-11	WAF PUSH AR OUT SENSOR ASSY
431	1380-101797-11	FOD LOCK SOLENOID ASSY
432	1380-101798-11	POD UNLOCK SOLENOID ASSY

433	1380-101799-11	POD DOOR OPEN SOLENOID ASSY
434	1380-101800-11	POD DOOR CLOSE SOLENOID ASSY
435	1380-101801-11	WAF PUSH SOLENOID ASSY
436	1380-101802-11	SMIF IND..MOTOR DC CABLE
437	1380-101803-11	SMIF IND..MOTOR SIGNAL CABLE
438	1380-101804-11	SMF INDEXER MOTOR ASSY
439	1380-101805-11	CARRIER UPPER PIN SENSOR ASSY
440	1380-101806-11	CAPPIER LOSER PIN SENSOR ASSY
441	040-000908-1	MOTOR DRIVER..CSD5814N-P
442	1380-000863-12	CAPPIER STAGE SWITCH..AB12C-6029/AE0

TEL Clean Track Mark 7 and Mark 8

Main Arm

No.	OEM Part No	Parts Name
1	1987-411639-1*	8-IPL-HSX8 ASSY
2	1910-125213-12	BASE ®
3	1310-496521-14	MOROT BASE
4	1903-300117-13	RIGHT ARM BASE
5	1903-300116-13	LEFT ARM BASE
6	1310-496525-13	BLOCK RV
7	1310-496526-13	BLOCK LV
8	1310-496528-12	BELT BLOCK B
9	1910-426515-12	TENSION HOUSING
10	1310-496534-12	BLOCK U
11	1310-496536-14	ARM BLOCK
12	1903-300118-13	MIDDLE ARM BASE
13	1310-392207-12	COVER C
14	1310-392208-12	COVER E
15	1310-496539-11	COVER G
16	1310-496540-11	COVER H
17	1310-496541-13	BLOCK
18	1310-392209-14	SIDE BLOCK V
19	1910-3212-3-11	HEAT INSULATING COVER (U)
20	1910-321204-11	HEAT INSULATING COVER (D)
21	1310-392212-16	ACRYLIC COVER BRACKET
22	1310-392213-14	DIDODE BRACKET
23	1310-496543-13	DIDODE BLOCK
24	310-491379-1	MOTOR SPACER
25	020-100448-1	SHOULDER BOLT..SH PHI 6*16 M5
26	1910-426514-11	TENSION SHAFT
27	044-001074-1	SUBSTRATE SUPPORT .. SA6-39
28	044-001059-1	SUBSTRATE SUPPORT .. SA6-21
29	018-001483-1	LM GUIDE..RSR12VMUUC1+330LHM G
30	023-000043-1	TIMING BELT..B60S3M789G
31	022-000045-1	BEARING..688ZZS
32	1902-411263-11	MOTOR PULLEY (S3M20F)
33	1910-433658-11	BOARD BRACKET
34	1910-433659-11	BOARD COVER
35	1310-497076-11	COVER F
36	1310-392533-12	COVER A`
37	1310-392534-12	COVER B`
38	1310-497237-11	SHUTTER AL (ST288)
39	1310-497238-11	SHUTTER AR (ST288)
40	1310-497236-14	PINCETTE SUPPORT A (ST288)
41	1310-392573-14	PINCETTE SUPPORT B (ST288)
42	1310-392574-14	PINCETTE SUPPORT C (ST288)
43	1910-426517-11	MYLAR SHEET (14*9)
44	021-100309-1	E-RING..ETW-6 SUS304
45	1985-456771-11	M/A 8 X PULLEY ASSY (A)
46	1985-456772-11	M/A 8 X PULLEY ASSY (B)
47	1910-451738-11	SENSOR BRACKET
48	1910-451737-11	FRONT SENSOR BRACKET
49	1910-451741-11	COVER

50	1386-453088-12	3P M/A S.S X MOTOR ASSY
51	1386-453046-11	3P M/A S.S X1 SENSOR HARNESS
52	1386-453947-11	3P M/A S.S X2 SENSOR HARNESS
53	1386-453048-11	3P M/A S.S X3 SENSOR HARNESS
54	1386-443508-11	3P MA8 WAF SENSOR ASSY
55	1381-650034-11	MAIN ARM H.S CONN C BOARD
56	381-643241-4	MAIN ARM WF SENSOR BOARD
57	1386-453042-12	3P M/A S.S C SIGNAL CABLE
58	1386-453045-11	3P M/A S.S X MOTOR CABLE
59	1386-457214-11	3P M/A S.S WAF SENSOR HARNESS
60	1985-422318-1*	8 VAC ARM BLOCK 48.5(X1-8)
61	1985-422320-1*	8 VAC ARM BLOCK 48.5(X1-5-6)
62	1910-324203-11	ARM BLOCK 8 (X1-8)
63	1910-324201-12	ARM BLOCK 8 (X1-5-6)
64	1910-428943-11	CAP 8 (X-8)
65	1910-428942-11	CAP 8 (X-5-6)
66	1910-428946-11	BLOCK 8 (X1)
67	1910-422908-12	VAC PACKING (PTFE)
68	027-101936-1	O-RING..BUTYL S-4 BLACK
69	028-003338-1	TUBE JOINT..M-5HL-4
70	1985-422319-1*	8 VAC ARM BLOCK 60.5(X2-8)
71	1985-422321-1*	8 VAC ARM BLOCK 60.5(X2-5-6)
72	1910-324204-11	ARM BLOCK 8 (X2-8)
73	1910-324202-12	ARM BLOCK 8 (X2-5-6)
74	1910-428943-11	CAP 8 (X-8)
75	1910-428942-11	CAP 8 (X-5-6)
76	1910-428947-12	BLOCK 8 (X2)
77	1910-422908-12	VAC PACKING (PTFE)
78	027-101936-1	O-RING..BUTYL S-4 BLACK
79	028-003338-1	TUBE JOINT ..M-5HL-4
80	1985-422322-1*	8 VAC ARM RELAY PIPE
81	1910-423350-11	RELAY PIPE (40)
82	028-008412-1	JOINT PARTS .. IN-233-463 GASKET
83	1910-427798-13	RELAY BLOCK (VZ)
84	028-003338-1	TUBE JOINT .. M-5HL-4
85	1985-422323-1*	8 VAC ARM WAF SENSOR BASE ASSY
86	1910-324205-11	DIDOCE BRACKET (VAC)
87	1910-325612-11	DIODE BRACKET (VAC-GL)
88	1910-428949-11	BLOCK U (VAC)
89	1910-428948-11	SIDE BLOCK V (VAC)
90	1985-422324-1*	8 VAC ARM VAC SENSOR JOINT ASSY
91	028-008412-1	JOINT PARTS .. IN-233-463 GASKET
92	1910-428944-11	SENSOR BRACKET (L)
93	1910-428945-11	SENSOR BRACKET ®
94	028-003337-1	TUBE JOINT .. M-5H-4
95	028-003338-1	TUBE JOINT .. M-5HL-4
96	028-002963-1	TUBE JOINT .. M-5UN
97	024-001538-1	SPEED CONTROLLER .. SPE-HS-M5
98	1987-411640-1*	8-IPL HS8Y ASSY
99	310-496440-1	F.C RETAINER
100	310-496443-6	BLOCK (B)
101	1310-497013-11	CABLE COVER
102	1310-392469-11	BOARD COVER
103	310-496444-6	SENSOR BRACKET

104	310-496439-1	ADJUSTMENT BLOCK (A)
105	1910-320928-13	MOTOR BRACKET
106	302-490105-1	PULLEY (SMALL)
107	023-000055-1	TIMING BELT .. 345-3GT-15
108	310-496445-2	STOPPER BLOCK
109	310-392105-6	BLOCK (A)
110	310-496447-1	BELT BLOCK
111	310-496448-1	BRACKET
112	310-496449-1	ADJUSTMENT BLOCK (B)
113	310-392099-5	SIDE BOARD ©
114	310-392100-5	SIDE BOARD (D)
115	310-496441-4	BLOCK (E)
116	310-496442-4	RIB BLOCK ©
117	026-001329-1	MAGNET CATCH .. TL-273-2-1789
118	047-000627-1	FLEXIBLE DUCT PART .. TKP0180-2B PIA
119	047-000628-1	FLEXIBLE DUCT PART .. TKP0180-2B PKA
120	1985-433853-11	M/A Y IDLER PULLEY ASSY
121	1985-433854-11	M/A Y DRIVE PULLEY ASSY
122	1386-448421-12	M/A H.S Y MOTOR ASSY
123	1386-449224-11	3P MA8 Y BP SENSOR ASSY
124	1381-650032-11	MAIN ARM H.S CONN A BOARD
125	1386-455463-11	3P M/A S.S SIGNAL INNER CABLE
126	1386-455464-11	3P M/A S.S DC INNER CABLE
127	1386-455465-11	3P M/A S.S STEP INNER CABLE
128	1386-455466-12	3P M/A S.S Z MOTOR INNER CABLE
129	1386-455467-11	3P M/A S.S Z ENC. INNER CABLE
130	1386-448915-12	M/A H.S A SIGNAL EXT CABLE
131	1386-448916-12	M/A H.S DC EXT CABLE
132	1386-448917-13	M/A H.S STEP MOTOR EXT CABLE
133	1386-448913-12	M/A H.S Z MOTOR EXT CABLE (1)
134	1386-448914-11	M/A H.S Z MOTOR EXT CABLE (2)
135	1386-448911-12	M/A H.S Y MOTOR EXT CABLE (1)
136	1386-448912-11	M/A H.S Y MOTOR EXT CABLE (2)
137	1987-412353-1*	8 IPL Y4 ASSY
138	1987-412354-1*	8 IPL Y6 ASSY
139	1987-412355-1*	8 IPL Y8 ASSY
140	1987-412356-1*	8 IPL Y10 ASSY
141	1987-412357-1*	8 IPL Y12 ASSY
142	1985-42232-1*	8 VAC ARM SOLENOID ASSY
143	028-008412-1	JOINT PARTS..IN-233-463-GASKET
144	1910-426973-11	TUBE HOLDER
145	012-002861-1	SOLENOID VALVE
146	028-002956-1	TUBE JOINT M-5J
147	028-003338-1	TUBE JOINT M-5HL-4
148	028-003337-1	TUBE JOINT M-5H-4
149	1910-429008-14	FC BRACKET VAC
150	1910-429009-11	SOL BRACKET VAC
151	310-496440-1	F.C HOLDER
152	1310-392516-13	8 PINCETTE 6
153	1910-430174-12	8 WAF BLOCK 5 (2P-45-F)
154	1910-421705-15	8PIQ GUODE5 (POLYIMIDE)
155	020-002044-1	BIND SCREW..M2.6*5 SUS
156	1910-349255-11	8 INCH PINCETTE
157	1910-430175-12	8 WAF BLOCK 5 (2P-45-F)

158	1910-421704-15	8PIQ GUODE5 (POLYIMIDE)
159	020-002044-1	BIND SCREW..M2.6*5 SUS
160	1910-220056-11	8 INCH VAC ARM
161	1910-428939-11	ARM CAP (W225-P1)
162	1910-439132-11	SUPPORT PIN
163	1910-439586-11	SHIM (T0.2)
164	1910-215093-11	VAC ARM (W148-P1)
165	1910-428941-11	ARM CAP (W148-P1)
166	1910-426574-11	V8-BLOCK
167	1910-215092-11	VAC ARM (W173-P1)
168	1910-428940-11	ARM CAP (W173-P1)
169	1910-426574-11	V8-BLOCK
170	1910-215091-11	VAC ARM (W225-P1)
171	1910-428939-11	ARM CAP (W225-P1)
172	1910-426574-11	V8-BLOCK
173	1910-428132-11	M3 SCREW PHI8.3
174	027-101936-1	OPRING...BUTYL S-4 BLACK
175	1910-111183-15	DRIVER BOX 200WPA COVER A
176	1910-321205-12	DRIVER BOX COVER B
177	1910-321176-12	CONNECTOR BRACKET
178	1910-425435-11	DRIVER BRACKET
179	044-000131-1	SUBSTRATE SUPPORT..TA-305
180	044-000135-1	SUBSTRATE SUPPORT..TB-300
181	1910-433437-12	DRIVER SPACER
182	044-001047-1	SUBSTRATE SUPPORT..AS6-10
183	1910-433437-12	FUSE BRACKET
184	040-570216-1	MOTOR DRIVER..PMM-BD-5702-4
185	1380-002053-11	MOTOR DRIVER...MSD011A1XX11
186	1380-002055-11	MOTOR DRIVER...MSD021A1XX10
187	1381-650031-13	MAIN ARM H.S DRIVER I/F BOARD
188	1386-448422-11	M/A H.S Y DRIVER SIGNAL CABLE
189	1386-44842-12	M/A H.S Y MOTOR DRIVER CABLE
190	1386-448424-11	M/A H.S Y MOTOR ENC. CABLE
191	1386-448425-11	M/A H.S Z DRIVER SIGNAL CABLE
192	1386-448426-13	M/A H.S Z MOTOR DRIVER CALE
193	1386-448427-11	M/A H.S Z MOTOR ENC CABLE
194	1386-448418-11	M/A H.S THETA DRIVER SIGNAL CABLE
195	1386-448419-11	M/A H.S X1 DRIVER SIGNAL CABLE
196	1386-448420-11	M/A H.S X2 DRIVER SIGNAL CABLE
197	1386-453075-11	3P M/A S.S X3 DRIVER SIGNAL CABLE
198	1386-448919-11	M/A H.S SIGNAL CABLE
199	1386-448920-11	M/A H.S A DC CABLE
200	1386-448921-12	M/A H.S DRIVER AC CONN CABLE
201	1386-453076-11	3P M/A S.S STEP MOTOR DRIVER HARNESS
202	1386-445635-11	IMC CONN CABLE1
203	1386-445635-11	IMC CONN CABLE2
204	1386-448909-12	M/A H.S DRIVER AC CABLE
205	1386-448910-13	M/A H.S DC POWER Cable

TEL Clean Track Mark 7 and Mark 8

Coat Unit

No.	OEM Part No	Parts Name
1	1987-411700-1*	UNIT BASE ASSY
2	1910-11-960-11	UNIT BASE
3	1903-100021-16	UNIT BASE (MK-8)
4	1910-217054-12	STRUT
5	1910-217055-12	STRUT
6	1910-217056-12	STRUT
7	1910-217057-12	STRUT
8	1910-438900-11	SWITCH BRACKET
9	1910-438899-11	SWITCH COVER
10	310-492813-2	REINFORCING PLATE (B)
11	310-492818-1	STRUT BASE PLATE (1)
12	310-492819-1	STRUT BASE PLATE (2)
13	1910-438898-11	BRACKET
14	1910-335258-11	COVER
15	1910-438889-11	SOLENOID VALVE BRACKET
16	1910-438888-11	BRACKET
17	1910-438883-11	BRACKET
18	1910-321982-11	CONNECTION BOARD BRACKET
19	310-490482-1	SPEED CONTROLLER FIXING BLOCK
20	1910-438884-11	BRACKET
21	310-490483-2	SPEED CONTROLLER SHAFT
22	1910-438903-11	BRACKET
23	026-100944-1	MAGNET CATCH..TL-148-1514
24	028-001189-1	TUBE JOINT .. PF
25	024-006915-1	FILTER .. ZX1-F
26	012-002468-1	NEEDLE VALVE .. GYX-0006
27	012-001227-1	SOLENOID VALVE .. VV5J3-32P-X221
28	024-007025-1	SPEED CONTROLLER .. SC-M5-L-X1
29	012-000446-1	MECHANICAL VALVE .. VM130-01-08
30	028-002954-1	TUBE JOINT .. M-5H-6
31	028-003339-1	TUBE JOINT .. M-5HL-6
32	028-003337-1	TUBE JOINT .. M-5H-4
33	028-003338-1	TUBE JOINT .. M-5HL-4
34	028-002956-1	TUBE FITTING .. M-5J
35	028-002961-1	TUBE JOINT .. M-5T
36	028-001191-1	TUBE JOINT .. RBF-SUS
37	028-001383-1	TUBE JOINT .. EC6-PT1/8-NI
38	028-001384-1	TUBE JOINT .. ELB6-PT1/8-NI
39	044-001126-1	SUBSTRATE SUPPORT .. SF5.5-10
40	044-001129-1	SUBSTRATE SUPPORT .. SB5.5-8
41	028-008410-1	TUBE JOINT .. IN-223-454
42	386-440770-2	8"SPIN CHUCK VAC SOL ASS'Y
43	386-440774-1	8"SCOAT CHUCK UP/VAC OFF SW
44	381-643196-5	SPIN UNIT CONN BOARD2
45	1381-645518-14	H.C LATCH BOARD
46	1986-420723-11	HC EXT CABLE
47	1987-411699-1*	MOTOR FLANGE ASSY
48	1903-200042-13	MOTOR FLANGE (SUS)
49	310-290008-8	MOTOR FLANGE BASE
50	310-492362-1	SHAFT SEAL HOLDER

51	310-492363-2	SHAFT SEAL
52	302-490037-2	LM SHAFT ADDITIONAL DRAWING
53	310-492369-1	VACUUM SEAL CASE
54	310-492370-1	VACUUM SEAL HOLDER
55	310-492365-1	TUBE RING
56	1910-430884-12	TUBE CONNECTOR
57	1310-497091-12	STOPPER (8")
58	024-006552-1	FLOATING JOINT .. JA20-8-125
59	018-001083-1	SLIDE BUSH .. SMK10W-SK
60	027-000003-1	SEAL .. AR 103499
61	027-101869-1	O-RING .. PERFULOLO AS568-013 BLACK
62	028-007304-1	TUBE JOINT .. C1N3/8-PT3/8ST
63	028-005382-1	TUBE JOINT .. C1N1/2-PT3/8ST
64	028-002954-1	TUBE JOINT .. M-5H-6
65	028-000041-1	TUBE JOINT .. M-01H-4
66	024-005671-1	AIR CYLINDER .. CQ2B32-40D-XB9
67	028-008294-1	QUICK JOINT .. SVHC06-06F
68	028-008295-1	QUICK JOINT .. SVHN06-06F
69	1386-444579-12	MK-8 CHUCK U/D SENSOR ASS'Y
70	380-090094-5	AC SERVOMOTOR .. USAHEM-03TE25
71	1380-001406-14	AC SERVOMOTOR .. 62BM006DXEAS-E
72	1385-391301-1*	GUIDE BLOCK ASSY
73	1310-496766-11	PITOT BLOCK
74	1310-496764-13	EXHAUST GUIDE
75	1910-429914-13	EXHAUST PIPE (1)
76	1910-429915-12	EXHAUST PIPE (2)
77	310-495888-1	PITOT NOZZLE ©
78	1310-496765-12	DRAIN GUIDE
79	028-003339-1	TUBE JOINT .. M-5HL-6
80	027-001026-1	PACKING .. 91H-Y00001-1 DRAIN
81	027-001027-1	PACKING .. 91H-Y00002-1 EXHAUST
82	1987-411698-1*	MK-8 SCAN ASSY
83	310-290143-5	BASE
84	310-390813-2	SIDE PLATE A
85	1910-438886-11	BRACKET
86	310-492045-1	MOTOR BRACKET
87	310-490309-1	HOUSING A
88	310-492040-1	HOUSING B
89	310-490311-1	BLOCK A
90	310-490856-1	BELT HOLDER
91	310-492041-1	SHAFT L
92	310-490018-2	SHAFT S
93	310-492042-1	COVER (A)
94	310-490025-1	SENSOR BRACKET
95	310-490313-3	SHUTTER A
96	310-492043-1	PULLEY LARGE
97	302-490028-2	PULLEY SMALL
98	302-490025-1	PULLEY A
99	310-492044-1	PULLEY B
100	310-490860-2	COLOR
101	310-492498-1	SHUTTER B
102	310-493572-1	END PLATE
103	310-490325-2	MANIFOLD
104	310-492499-4	Z BASE
105	310-490308-1	RIB

106	310-492059-1	Y BASE
107	310-490318-2	SENSOR BRACKET
108	310-490319-3	BRACKET
109	310-492061-1	COVER (B)
110	902-411025-1	SHAFT
111	310-492500-1	RIB (A)
112	310-492504-2	COVER
113	310-290170-3	TOP COVER
114	310-495318-2	HOOK BRACKET
115	910-414871-2	PANEL HOOK
116	910-412671-1	HOSE HOLDER COVER
117	910-412672-1	SPACER PHI8
118	018-000014-1	LINEAR WAY .. LWLF24C 1R400T1H/U
119	022-101376-1	BEARING .. RF-1980ZZ
120	023-100916-1	TIMING BELT .. 300-XL-025U
121	023-100917-1	TIMING BELT .. 80-XL-025U
122	018-001082-1	SLIDE BUSH .. SMK8GWUU-SK
123	024-005721-1	SPEED CONTROLLER .. SPR-HS-M5
124	024-006579-1	AIR CYLINDER .. CU16-25D
125	026-101380-1	RUBBER VIBRATION ISOLATOR .. SPM-47-G2
126	128-001211-1	TUBE JOINT .. TSH4-M5M
127	028-003337-1	TUBE JOINT .. M-5H-4
128	028-003338-1	TUBE JOING .. M-5HL-4
129	017-000269-1	FLAT TUBE .. UML-404-TE
130	386-440776-3	8"SPIN MTR SCAN ARM HOME SENS
131	381-639228-2	SCAN ARM CONNECTION BRD
132	381-639227-3	SCAN ARM SENSOR BRD.
133	386-440777-1	8"SCAN ARM FLEX CABLE
134	386-440778-1	8"SCAN ARM CABLE
135	1985-429192-1*	COAT ARM ASSY
136	1910-425611-14	COATER ARM (MHQ2)
137	1910-425609-12	CLINDER MOUNT (MHQ2)
138	1910-426723-11	FRONT COVER
139	1910-425835-12	CLAMP PAWL (MHQ2-16D)
140	310-492060-1	ARM BASE
141	310-491175-1	BLOCK (A)
142	310-439210-2	MANIFOLD A
143	310-493598-1	HOSE BRACKET
144	310-492503-1	BRACKET
145	1910-421158-11	STOPPER
146	1910-421159-11	SLIDE BLOCK
147	1910-421160-11	SPACER
148	024-014184-1	AIR CYLINDER .. MHQ2-16D-X1737
149	025-100063-1	SPRING .. 2114
150	028-002968-1	TUBE JOINT .. MS-5J
151	1985-445595-1*	RRC ARM
152	1910-338799-11	ARM
153	1910-441433-12	BLOCK
154	1910-451461-12	BRACKET
155	1910-451868-11	NOZZLE HOLDER
156	1910-451463-11	LOCK SCREW
157	1910-432352-11	NOZZLE PIPE (2)
158	1310-498367-11	TUBE HOLDER (1)
159	1310-498368-11	TUBE HOLDER (2)
160	1910-432302-11	TUBE HOLDER (6)

161	1910-432303-11	TUBE HOLDER (7)
162	1985-445597-1*	MK-7/8 RRC DRAIN
163	1910-340255-11	DRAIN PAN
164	1910-436698-11	DRAIN BLOCK-20
165	1910-432314-11	8-BRACKET
166	1910-436580-11	SUPPORT
167	028-002197-1	TUBE JOINT .. F900-H-6.35A
168	1987-411696-1*	NEW 8" E.B.R ASSY
169	310-391866-1	SIDE RINSE ARM
170	310-495857-1	SHAFT BLOCK
171	310-495858-1	SHAFT PLATE
172	310-494999-1	NUT PLATE
173	310-495001-1	ROD COLLAR
174	310-495002-2	GUIDE BASE
175	310-495003-2	SHUTTER PLATE
176	310-494971-2	COVER BLOCK1
177	310-495005-1	COVER BLOCK 2
178	310-494956-1	STOPPER
179	310-494957-1	SENSOR BRACKET
180	310-494958-1	ARM COVER
181	018-000979-1	SLIDE PACK.. MR615E+25LE
182	024-003315-1	SPEED CONTROLLER .. AS1201F-M5-04
183	024-008819-1	AIR CYLINDER .. CU10-5D-XB9
184	310-494972-1	KNOB SCREW
185	310-494973-1	KNOB NUT
186	386-440787-4	8"E.B.R.IN/OUT SENSOR .. ASSY
187	1087-411695-1*	8" ROTARY ARM ASSY
188	310-390703-4	BASE PLATE
189	310-492747-1	Z-AXIS BASE PLATE
190	310-492748-2	HOUSING
191	310-492749-2	COLLAR (A)
192	310-492751-1	BEARING CAP
193	310-492752-2	ACTUATOR BASE
194	310-492762-1	STOPPER (B)
195	310-492757-1	SPACE BLOCK
196	310-492758-1	CYLINDER PLATE
197	310-492759-2	CYLINDER BRACKET
198	310-492760-1	WASHER
199	310-492761-2	COLLAR (A)
200	018-001515-1	LM GUIDE.. RSR9WMUU+90LM G=15
201	310-495118-1	ECCENTRIC STOPPER
202	023-000203-1	COUPLING .. 3005M-8*8
203	022-100123-1	BEARING .. 6001ZZ
204	028-003338-1	TUBE JOINT .. M-5HL-4
205	1310-496613-11	SA BRACKET
206	025-000200-1	SHOCK ABSORBER .. KSHA 6*5C-A
207	310-492755-1	STOPPER BRACKET
208	1310-497188-11	STOPPER (6")
209	1310-496610-11	COVER BRACKER (1)
210	1310-496011-11	COVER BRACKER (2)
211	1310-497189-11	COVER (1)
212	1310-392543-11	COVER (2)
213	310-493488-2	SHAFT
214	386-440785-1	8"SPIN CYLINDER SCAN U/D SENS
215	386-440786-1	8"SPIN CYLINDER SCAN I/O SENS

216	1985-412564-1*	E.B.R NOZZLE PARTS (A)
217	1910-423074-11	NOZZLE CLAMP
218	1910-423588-11	ARM BRACKET
219	1910-423589-12	NOZZLE BEAM (8")
220	910-416948-3	NOZZLE HOLDER (2)
221	310-495023-3	CHIP HOLDER (A)
222	310-495025-2	CHIP TYPE-2
223	1987-412363-1*	E.B.R SCAN ASSY (MK-8)
224	1910-323101-12	MSR BASE (2-8")
225	1910-321748-11	DRAIN TANK (MSR)
226	1910-323103-12	SCAN COVER (2-8")
227	1910-434600-12	ENCODER
228	1910-426654-11	SLIT HOLDER
229	1910-437520-11	MOTOR BASE
230	1910-437820-11	MOTOR BRACKET
231	1910-426599-12	COVER BRACKET
232	1910-426209-11	SPRING SHAFT
233	1910-426210-12	SPRING BRACKET
234	1910-437821-11	NEN SENS BRKT
235	1910-426593-11	SENSOR BRACKET (HOME)
236	1910-426213-11	SENSOR SHUTTER
237	1902-411225-11	MOTOR PULLEY
238	024-011624-1	AIR CYLINDER .. CZLS-SD25-50-A
239	023-000911-1	TIMING BELT .. 192-3GT-9
240	025-000035-1	SPRING .. 2123
241	028-003338-1	TUBE JOINT .. M-5HL-4
242	028-002152-1	TUBE JOINT .. F900-F-6.35
243	1910-426769-11	COVER BRACKET (2)
244	1902-411132-12	PULLEY (P48)
245	1910-426594-11	ADJUSTING NUT
246	1910-426595-11	LOCKNUT
247	1910-426596-11	STOP COLLAR (PHI 10)
248	1910-426597-11	CUSHION
249	1386-451848-12	MK-7,8 E.B.R. MOTOR ASSY
250	1386-451849-13	MK-7,8 SPIN E.B.R. U/D .. SENSOR ASSY
251	1386-451850-13	MK-7,8 SPIN E.B.R. ENC .. SENSOR ASSY
252	1386-450326-13	SPIN E.B.R. ENC HARNESS
253	1985-420201-1*	MSR NOZZLE 2 AASY (MK-8)
254	1910-426651-11	ARM BLOCK 2 (MSR)
255	1910-426652-11	BLOCK CAP (2)
256	1910-427772-11	NOZZLE BEAM 2 (MSR-8")
257	1910-426655-11	NOZZLE HOLDER
258	1910-426244-11	NOZZLE CAP
259	1910-425440-11	REDUCING TUBE (24G)
260	1910-426656-11	OLDER CAP
261	1910-427476-11	REDUCING TUBE (0.23)
262	1910-427477-11	REDUCING TUBE (0.30)
263	1987-411697-1*	NOZZLNOZZLE 4 ASSY
264	1310-0392360-14	BASE
265	1910-321936-11	NOZZLE SIDE PLATE
266	1310-496827-12	SIDE PLATE A
267	1310-496828-12	SIDE PLATE B
268	310-492567-4	DIAPHRAGM
269	131-496834-12	HOUSING
270	1310-496831-13	BELT HOLDER

271	310-493580-1	COVER D
272	1910-439986-12	COVER A
273	1310-496830-14	COVER B
274	1310-496836-12	MOTOR BRACKET
275	310-492576-1	HOUSING (A)
276	1910-431144-11	SHAFT S
277	302-490034-1	PULLEY A
278	302-490035-1	PULLEY B
279	3-2-490064-1	SHAFT S
280	310-492581-2	WIRE HOLDER
281	1310-496833-12	FIXING PLATE
282	1310-496835-12	SENSOR BRACKET A
283	910-315161-1	NOZZLE BASE A
284	910-315162-2	THINNER POT A
285	910-315163-1	DRAIN BLOCK A
286	910-315164-3	DRAIN MANIFOLD A
287	310-492488-3	PL 12 NUT
288	310-491625-1	ENCODER SLIT
289	1310-496822-12	ENCODER HOLDER
290	1310-496945-11	SENSOR SHUTTER
291	026-10944-1	MAGNET CATCH .. TL-148-1514
292	022-101376-1	BEARING .. RF-1980ZZ
293	018-000168-1	LINEAR BUSH .. LM10MUJ
294	023-100921-1	TIMING BELT .. 200-XL-037U
295	027-102595-1	O-RING .. PERFULOLO S-22.4 BLACK
296	028-008407-1	TUBE JOINT .. IN-233-451
297	017-001685-1	TEFLON TUBE .. F-9003-PL-12A-L1500-S20
298	1310-496946-11	SENSOR BRACKET
299	386-440791-2	8"NOZZLE HEAD SENSOR ASS'Y
300	1986-420720-11	8"NOZZLE HCHANGER HOME SENSOR
301	1386-444809-11	8"NOZZLE CHANGER (ENC.) MTR ASSY
302	1380-002140-11	SOLVENT BATH
303	1985-457766-1*	COAT CUP HOLDER ASSY 1LINE
304	310-492957-2	FIXED ROD
305	310-492417-1	SHAFT STAND
306	1910-430029-11	REDUCING TUBE 21G
307	1310-496950-12	NOZZLE BRACKET
308	310-492955-3	PACKING B
309	028-008412-1	JOINT PART
310	1310-497020-11	PACKING
311	1910-427793-11	TUBE GUIDE
312	310-492954-1	FIXED BLOCK 1
313	1903-200035-11	CUP BASE
314	1903-200109-11	DRAIN PAN
315	1910-334286-12	NOZZLE BRACKET
316	1310-497605-11	NOZZLE CAP
317	028-002197-1	TUBE JOINT
318	1910-423429-11	STOP PLATE
319	1380-000872-12	MK-8 LOWER CUP PPS
320	1380-000989-14	8" UPPER CUP (FR-PP)\
321	1380-000990-12	8" INNER CUP (FR-PP)
322	1386-462337-1*	COAT CONNECTION(MK-7,8)
323	1393-745520-11	H.C EXT CABLE
324	1393-739483-1	DUMMY DISPENSE CABLE
325	1393-740767-1	8" SPIN SOLENOID FLAT CABLE

326	1393-740796-1	8" SPIN STEP CONT CABLE
327	1393-740778-1	8" SCAN ARM CABLE
328	1393-739487-1	SPIN USER BRD CABLE
329	1393-740793-1	8" SPIN MTR STOP SW CABLE
330	1393-740795-1	8" EXHAUST ALM CABLE
331	1393-740789-1	8" NOZZLE CHANGER MOTOR CALE
332	1385-411404-1*	MK-7,8 T&H ASSY CP
333	1310-381013-12	PACKING 2 CP
334	310-290627-6	DUCT X
335	310-391912-1	PACKING
336	1910-213945-11	T&H SENSOR BRACKET
337	1310-290791-16	T/H HOOD
338	026-100944-1	MAGNET CATCH
339	310-496110-1	BRACKET C
340	310-496111-11	BRACKET D
341	1310-496855-13	T/H BOX BRACKET
342	1310-181011-15	T/H BOX CP
343	1310-497043-11	BRACKET
344	1310-497095-11	MAGNET PLATE 1
345	1310-497096-11	MAGNET PLATE 2
346	1310-497097-11	MAGNET PLATE 3
347	1910-329850-11	T/H BOX COVER 1 CP
348	1910-320851-11	T/H BOX COVER 2 CP
349	1385-391376-1*	MK-8 COAT COVER ASSY
350	1310-496948-11	SIDE COVER BRACKET 1
351	1310-496650-12	SIDE COVER BRACKET 2
352	310-492825-1	SIDE COVER BRACKET 3
353	310-492826-1	SIDE COVER BRACKET 4
354	310-496012-2	BRACKET B
355	310-496013-2	BRACKET C
356	1310-496651-11	MAGNET PLATE
357	1310-496988-12	COVER GUIDE 1
358	1310-496989-12	COVER GUIDE 2
359	1310-496953-11	COVER GUIDE L
360	1310-497002-12	COVER GUIDE R
361	1910-443000-11	COVER SUPPORT
362	1310-497018-14	COVER 1
363	1310-497019-14Q	COVER 2
364	1310-392502-14	COVER F
365	1310-497004-14	CEBTER COVER C
366	1310-496986-13	SIDE COVER 3
367	1310-496987014	SIDE COVER 4
368	310-490510-1	COLLAR
369	024-008470-1	NOZZLE TIP

TEL Clean Track Mark 7 and Mark 8

Dev Unit

No.	OEM Part No	Parts Name
1	1985-417669-1*	UNIT BASE ASSY
2	1910-11-960-11	UNIT BASE
3	1903-100021-16	UNIT BASE (MK-8)
4	1910-217054-12	POLE
5	1910-217055-12	POLE
6	1910-217056-12	POLE
7	1910-217057-12	POLE
8	1910-438900-11	SWITCH BRACKET
9	1910-438899-11	SWITCH COVER
10	310-492813-2	REINFORCING PLATE B
11	310-492818-1	BASE PLATE FOR PILLAR 1
12	310-492819-1	STRUT BASE PLATE (2)
13	1910-438898-11	BRACKET
14	1910-335258-11	COVER
15	1910-438889-11	SOLENOID VALVE BRACKET
16	1910-438888-11	BRACKET
17	1910-438883-11	BRACKET
18	1910-321982-11	CONNECTION BOARD BRACKET
19	310-490482-1	SPEED CONTROLLER FIXING BLOCK
20	1910-438884-11	BRACKET
21	310-490483-2	SPEED CONTROLLER SHAFT
22	1910-438903-11	BRACKET
23	026-100944-1	MAGNET CATCH..TL-148-1514
24	028-001189-1	TUBE JOINT .. PF
25	024-006915-1	FILTER .. ZX1-F
26	012-002468-1	NEEDLE VALVE .. GYX-0006
27	012-001227-1	SOLENOID VALVE .. VV5J3-32P-X221
28	024-007025-1	SPEED CONTROLLER .. SC-M5-L-X1
29	012-000446-1	MECHANICAL VALVE .. VM130-01-08
30	028-002954-1	TUBE JOINT .. M-5H-6
31	028-003339-1	TUBE JOINT .. M-5HL-6
32	028-003337-1	TUBE JOINT .. M-5H-4
33	028-003338-1	TUBE JOINT .. M-5HL-4
34	028-002956-1	TUBE FITTING .. M-5J
35	028-002961-1	TUBE JOINT .. M-5T
36	028-001191-1	TUBE JOINT .. RBF-SUS
37	028-001383-1	TUBE JOINT .. EC6-PT1/8-NI
38	028-001384-1	TUBE JOINT .. ELB6-PT1/8-NI
39	044-001126-1	SUBSTRATE SUPPORT .. SF5.5-10
40	044-001129-1	SUBSTRATE SUPPORT .. SB5.5-8
41	028-008410-1	TUBE JOINT .. IN-223-454
42	985-313935-*	E2 UNIT PARTS V8-8
43	1910-321247-11	TUBE RETAINER 8"
44	1910-418268-11	TUBE RETAINER B
45	1987-411699-1*	MOTOR FLANGE ASSY
46	1903-200042-13	MOTOR FLANGE (SUS)
47	310-290008-8	MOTOR FLANGE BASE
48	310-492362-1	SHAFT SEAL HOLDER
49	310-492363-2	SHAFT SEAL
50	302-490037-2	LM SHAFT ADDITIONAL DRAWING

51	310-492369-1	VACUUM SEAL CASE
52	310-492370-1	VACUUM SEAL RETAINER
53	310-492365-1	TUBE RING
54	1910-430884-12	TUBE CONNECTOR
55	1310-497091-12	STOPPER (8")
56	024-006552-1	FLOATING JOINT .. JA20-8-125
57	018-001083-1	SLIDE BUSH .. SMK10W-SK
58	027-000003-1	SEAL .. AR 103499
59	027-101869-1	O-RING .. PERFULOLO AS568-013 BLACK
60	028-007304-1	TUBE JOINT .. C1N3/8-PT3/8ST
61	028-005382-1	TUBE JOINT .. C1N1/2-PT3/8ST
62	028-002954-1	TUBE JOINT .. M-5H-6
63	028-000041-1	TUBE JOINT .. M-01H-4
64	024-005671-1	AIR CYLINDER .. CQ2B32-40D-XB9
65	028-008294-1	QUICK JOINT .. SVHC06-06F
66	028-008295-1	QUICK JOINT .. SVHN06-06F
67	1386-444579-12	MK-8 CHUCK U/D SENSOR ASS'Y
68	380-090094-5	AC SERVOMOTOR .. USAHEM-03TE25
69	1380-001406-14	AC SERVOMOTOR .. 62BM006DXEAS-E
70	1385-391301-1*	GUIDE BLOCK ASSY
71	1310-496766-11	PITOT BLOCK
72	1310-496764-13	EXHAUST GUIDE
73	1910-429914-13	EXHAUST PIPE (1)
74	1910-429915-12	EXHAUST PIPE (2)
75	310-495888-1	PITOT NOZZLE ©
76	1310-496765-12	DRAIN GUIDE
77	028-003339-1	TUBE JOINT .. M-5HL-6
78	027-001026-1	PACKING .. 91H-Y00001-1 DRAIN
79	027-001027-1	PACKING .. 91H-Y00002-1 EXHAUST
80	1987-411701-1*	E2 SCAN ASSY
81	910-211652-4	BASE
82	910-314858-3	RAIL BASE
83	910-314859-1	SIDE PLATE
84	1910-421820-13	RAIL GUIDE
85	910-416759-2	CYLINDER BASE
86	910-416760-2	MANIFOLD A
87	910-416761-1	BELT BLOCK
88	910-416762-2	SHUTTER
89	1910-438902-12	CYLINDER BRACKET
90	910-416764-1	COLLAR
91	910-416765-2	BEARING 1
92	1910-438901-11	BRACKET
93	1910-438885-11	TUBE RETAINER
94	910-416769-1	ADJUSTMENT BOLT
95	910-416770-1	FIXING NUT
96	910-211653-4	TOP COVER
97	910-416771-1	COVER 1
98	910-416772-3	COVER 2
99	1903-400051-12	ARM BASE 8"
100	310-490309-1	HOUSING A
101	310-492040-1	HOUSING B
102	310-494658-1	MOTOR BRACKET
103	1910-43886-11	BRACKET
104	310-491625-1	ENCODER SLIT
105	310-492296-1	SLIT HOLDER

106	302-490025-1	PULLEY A
107	302-490058-1	TIMING PULLEY 10XL
108	302-490028-2	PULLEY SMALL
109	310-492043-1	PULLEY LARGE
110	310-490018-2	SHAFT S
111	310-494657-2	SHAFT L
112	910-416773-3	BRACKET A
113	910-416774-2	BRACKET B
114	018-001471-1	LM GUIDE..2RSR12WMUUC1+390LM
115	902-411023-2	LM GUIDE ADDITIONAL WORK DRAWING
116	022-101376-1	BEARING...RF-1980ZZ
117	023-100916-1	TIMING BELT..300-XL-025U
118	023-100917-1	TIMING BELT..80-XL-025U
119	024-003574-1	SPEED CONTROLLER..AS1211F-M5-04
120	024-010531-1	AIR CYLINDER..CDU16-30D-90-XB9
121	028-003337-1	TUBE JOINT..M-5-4
122	028-003338-1	TUBE JOINT..M-5HL-4
123	017-000269-1	FLAT TUBE..UML-404-TE
124	026-101380-1	RUBBER CUSHION..SPM-47-G2
125	044-000044-1	SUBSTRATE SUPPORT..EM-3
126	028-002960-1	TUBE JOINT..M-5P
127	028-002956-1	TUBE JOINT..M-5J
128	381-643067-1	E2 SCAN ARM CONN BOARD
129	381-643065-1	E2 SCAN ARM SENSOR BOARD
130	386-440775-1	8" SPIN MTR SCAN ARM MOTOR ASSY
131	386-440776-3	8" SPIN MTR SCAN ARM HOME SENS
132	386-44309-1	E2 SCAN ARM FLEX CABLE 8"
133	1985-411787-1*	E2 NOZZLE ARM ASSY (1 SYSTEM)
134	1310-496912-12	NOZZLE BRACKET 2
135	910-414549-2	NOZZLE BRACKET 2
136	910-416733-1	NOZZLE SHAFT
137	910-416734-1	NUT M8
138	1910-427217-12	ARM BLOCK A
139	1910-430971-11	NOZZLE ARM
140	1985-414069-1*	E2 NOZZLE ASSY 8"
141	910-314875-5	NOZZLE CAP 8"
142	028-003416-1	RESIN JOINT..S-UF-W2YATL
143	1910-417680-11	TUBE HOLDER
144	028-009858-1	RESION JOINT..MC P-9 1/4 P
145	017-002017-1	FLEXIBLE TUBE..PENCHEM CT1/4"
146	027-001485-1	O-RING...BUTYL AS568-162 BLACK
147	027-101874-1	O-RING.. PARFLO S-6 BLACK
148	017-000419-1	FLEXIBLE TUBE..PENCHEM CT1/4"
149	028-003513-1	RESION JOINT..UNION CT 1/4
150	027-001465-1	O-RING ..BUTYL P-6 BLACK
151	1985-411429-1*	E2 NOZZLE BATH ASSY 8INCH
152	1910-317686-13	BATH BOX 8"
153	1910-317659-17	NOZZLE BATH 8"
154	1910-317684-15	DRAIN TRAP
155	1380-001024-11	CENTER BAR 8"
156	1910-420715-11	DRAIN PIPE 1
157	1910-420675-13	DRAIN PIPE 2
158	1910-421459-11	LOCK NUT
159	027-001487-1	O-RING..BUTYL AS568-257 BLACK
160	027-101832-1	O-RING.. BUTYL P-10 BLACK

161	910-416848-1	FILTER BRACKET
162	024-002967-1	FILTER..WGGB 01K
163	025-000007-1	SPRING..1070
164	985-313935-1*	E2 UNIT PARTS V8-8
165	910-416846-2	NOZZLE BATH BASE 8"
166	910-417093-2	BRACKET V8
167	910-315105-3	MANIFOLD E2-A
168	028-008294-1	QUICK JOINT...SVHC06-06F
169	028-008295-1	QUICK JOINT...SVHN06-06F
170	1985-417415-1*	E2 NOZZLE (8"-FORMATION)
171	1910-424388-11	NUT PLATE (E2-8)
172	020-000009-1	CAP SCREW..M3*10
173	1987-411702-1*	MK-8 RINSE SCAN ASSY
174	1310-290762-14	SCAN BASE
175	1310-392296-13	U/B BASE
176	1310-496684-12	BLOCK 1
177	1310-496685-12	BLOCK 2
178	1310-496686-11	LOCK NUT
179	1310-496688-11	STOPPER 1
180	1310-496689-12	HOUSING L
181	1310-496690-15	HOUSING U
182	1310-496691-11	STOPPER RETAINER
183	1310-496692-13	SA BRACKET
184	1310-496693-11	CYLINDER BRACKET
185	1310-496694-13	ROD END
186	1310-496695-12	COLLAR
187	1310-496696-15	SHAFT
188	1310-496697-13	COVER BRACKET
189	1310-496698-13	SENSOR BRACKET U
190	1310-496699-12	SENSOR BRACKET L
191	1310-496700-13	ADJUSTMENT SCREW
192	1310-496701-11	SHUTTER 1
193	1310-496702-11	SHUTTER 2
194	1310-496703-13	SHUTTER END
195	1310-496704-12	LINK RETAINER
196	1310-496706-14	COVER 2
197	1310-496709-13	STOPPER 2
198	1310-392483-12	DRAIN BEARING
199	018-000354-1	LM GUIDE
200	022-100762-1	BEARING...6901ZZ
201	025-000200-1	SHOCK ABSORBER
202	021-100254-1	E-RING
203	1310-497061-11	LINK
204	1310-392531-12	COVER 1
205	1310-497062-11	PIN 1
206	1310-497063-11	PIN 2
207	1310-497060-11	CLEVIS
208	021-100308-1	E-RING
209	021-100466-1	E-RING
210	1310-496890-12	GUIDE 1
211	1310-497161-11	COVER 3
212	028-000041-1	TUBE JOINT..M-01H-4
213	024-011140-1	AIR CYLINDER..CQ2D20-F8623-25
214	044-000044-1	SUBSTRATE SUPPORT..EM-3
215	044-000045-1	SUBSTRATE SUPPORT..EM-5

216	1986-420719-11	MK-8 CYLI SCAN U/D SENSOR ASSY
217	1386-444581-11	MK-8 CYLI SCAN I/O SENSOR ASSY
218	028-003381-1	TUBE JOINT...M-5HI-4
219	1385-391299-1*	MK-8 RINSE NOZZLE ASSY
220	1310-497015-13	RINSE ARM
221	1310-497014-13	RINSE ARM HOLDER
222	310-496407-2	HOLDER BRACKET
223	310-496408-2	NOZZLE HOLDER
224	1910-422874-11	NOZZLE HOLDER
225	910-415659-3	NUT
226	028-00676-1	RINSE JOINT...F-W2A
227	1987-411703-1*	OUT CUP BASE ASSY
228	1910-426113-12	CYLINDER SUPPORT 1
229	1910-422061-13	CYLINDER SUPPORT 2
230	1310-290776-12	OUTER CUP BASE
231	1310-496879-11	CLEVIS
232	302-490067-1	LM SHAFT ADDITIONAL DRAWING
233	1910-423158-11	ROD END
234	028-000041-1	TUBE JOINT...M-01H-4
235	018-001085-1	SLIDE BUSH .. SMK12W-SK-1
236	1386-444580-12	MK-8 OUT CUP U/D SENSOR ASSY
237	385-390960-*	CUP HOLDER
238	310-390771-3	CUP FIXING PLATE
239	310-492973-2	FIXING ROD
240	310-492417-1	SHAFT STAND
241	1386-462336-1*	DEVE CONNECTION MK-7,8
242	1986-420723-11	H.C EXT CABLE
243	1393-740767-1	8" SPIN SOLENOID FLAT CABEL
244	1986-420733-11	8" SPIN STEP CONT CABEL
245	1393-743092-1	E2 SCAN ARM CABLE
246	1393-739487-1	SPIN USER BRD CABLE
247	1986-420725-11	8" SPIN MTR STOP SW CABLE
248	1986-420731-11	8" EXHAUST ALM CABLE
249	1385-391377-1*	DEV UNIT COVER ASSY
250	1310-496948-11	SIDE COVER BRACKET 1
251	1310-496650-12	SIDE COVER BRACKET 2
252	310-492825-1	SIDE COVER BRACKET 3
253	310-492826-1	SIDE COVER BRACKET 4
254	310-496012-2	BRACKET B
255	310-496013-2	BRACKET C
256	1310-496651-11	MAGNET PLATE
257	1310-496988-12	COVER GUIDE 1
258	1310-496989-12	COVER GUIDE 2
259	1310-497185-12	COVER GUIDE L DEV
260	1310-497186-11	COVER GUIDE R DEV
261	1910-443000-11	COVER SUPPORT
262	1310-497018-14	COVER 1
263	1310-497019-14Q	COVER 2
264	1310-392502-14	COVER F
265	1310-497187-13	CENTER COVER D
266	1310-496986-13	SIDE COVER 3
267	1310-496987014	SIDE COVER 4
268	1310-497234-12	SUPPORT BAR
269	1310-497235-11	SUPPORT BAR BRACKET
270		DEV SPLAY

271	017-000374-1	PLIABLE TUBE
272	310-492488-3	PL12 NUT
273	310-390662-3	HOLDER A
274	310-492490-3	1/4" NUT
275	027-101688-1	O-RING...NITRYL S-12
276	310-390661-3	TK HOLDER
277	027-101895-1	O-RING ..PARFLO S-3
278	310-391313-2	PAN
279	017-000371-1	PFA TUBE 1/8"
280	028-008408-1	MINIATURE JOINT
281	310-493325-2	T.K PACKING
282	024-004433-1	SPLAY CHIP
283	310-492639-3	CAP
284	027-101581-1	O-RING...NITRYL S-14
285	310-390663-2	HOLDER BRACKET
286	910-414627-3	NOZZLE BRACKET 4
287	910-415174-2	VAC. NOZZLE
288	910-415264-2	VAC. NOZZLE RETAINER
289	028-008407-1	MINIATURE JOINT
290	910-414548-2	NOZZLE BRACKET 1
291	910-414549-2	NOZZLE BRACKET 2
292	910-413839-2	NOZZLE BRACKET 3
293	017-000371-1	PFA TUBE 1/4"
294		DEV NOZZLE
295	017-000374-1	PLIABLE TUBE
296	310-492488-3	PL 12 NUT
297	310-390663-2	HOLDER B
298	027-101581-1	O-RING.. NITRYL S-14
299	017-000371-1	PFA TUBE 1/4"
300	310-390662-3	HOLDER A
301	310-492490-3	1/4" NUT
302	027-101688-1	O-RING..NITRYL S-12
303	1910-420354-14	DEV NOZZLE 4 ADAPTER
304	027-101875-1	O-RING...PARFLO S-8
305	1910-420353-11	DEV NOZZLE 4 W
306	910-415265-2	NOZZLE BRACKET 5
307	910-413839-2	NOZZLE BRACKET 3
308	910-414549-2	NOZZLE BRACKET 2
309	910-414548-2	NOZZLE BRACKET 1
310	1385-490440-1*	H NOZZLE SEPARATION (8") ASSY
311	1310-482906-11	UNDER BODY NS
312	1310-498653-12	OVER PLATE 8"
313	1910-420354-14	DEV NOZZLE 4 ADAPTER
314	310-492490-3	1/4" NUT
315	310-391669-3	HOLDER C
316	310-391667-2	HOLDER A
317	310-492488-3	PL 12 NUT
318	1310-498656-12	TURNING BLOCK 8"
319	1310-498642-11	NOZZLE BROCKET
320	027-001658-1	O-RING..BUTYL S-46 BLACK
321	027-101875-1	O-RING...PARFLO S-8
322	027-101688-1	O-RING..NITRYL S-12
323	1310-498703-11	HOLE (SHAFT)
324	017-002518-1	TEFLON TUBE
325	027-101581-1	O-RING.. NITRYL S-14

326	1910-421391-12	NOZZLE ARM L=270
327	1910-427217-12	ARM BLOCK A
328	1985-437476-1*	H NOZZLE SEPARATION (6"-2)
329	1310-482929-11	UNDER BODY-NS (6")
330	1310-498666-11	NOZZLE OVER BODY
331	1910-420354-14	DEV NOZZLE 4 ADAPTER
332	310-492490-3	A1/4" NUT
333	310-391669-3	HOLDER C
334	310-391667-2	HODER A
335	310-492488-3	PL12 NUT
336	1910-438061-11	TURNING BLOCK
337	1910-438062-11	NOZZLE BRACKET
338	1910-438063-11	NOZZLE BRACKET
339	1310-498711-11	MIDDLE (SHIFT)
340	1910-419784-12	NOZZLE ARM (2)
341	1910-429214-11	ARM BLOCK (B)
342	1910-429215-11	ARM BLOCK©
343	027-101875-1	O RING .. PARFLO S-8 BLACK
344	027-101688-1	O RING .. NYTRYL S-12 BLACK
345	017-002518-1	TEFLON TUBE .. NO.90003-PL 12A L=850
346	027-101581-1	O RING .. NYTRYL S-14 BLACK
347	027-101877-1	O RING .. PARFLO S-34 BLACK

TEL Clean Track Mark 7 and Mark 8

LHP Unit

No.	OEM Part No	Parts Name
1	1985-412705-1*	HP SUB UNIT ASSY
2	1910-110864-19	MAIN BLOCK
3	1903-200023-13	EXHAUST SUPPORT (HP-L)
4	1903-200022-13	EXHAUST SUPPORT (HP-R)
5	1910-320626-13	EXHAUST BOX
6	1310-496574-15	S COVER A
7	1310-496575-13	S COVER B
8	1310-496576-13	S BOLT
9	1903-300176-11	SHUTTER ARM
10	1903-300179-11	3 PIN ARM
11	1904-400091-11	EXHAUST INTERRUPTER
12	1910-422803-12	DAMPER
13	1910-422804-11	ROD
14	1910-320627-12	UNDER COVER
15	1903-400102-11	3 PIN ARM
16	1903-300013-14	3 PIN ARM © WORKING DRAWING
17	1903-300153-12	SHUTTER ARM
18	1310-496582-14	P BLOCK
19	1310-290722-16	HT COVER
20	1904-400087-11	POSITION BRACKET
21	1310-290723-14	BRACKET COVER
22	1310-496603-13	GUIDE PIN
23	1310-497102-13	COVER SUPPORT (B, DHP)
24	024-015109-1	AIR CYLINDER .. JDAS20*20-1331W
25	024-015110-1	AIR CYLINDER .. JDAS20*25-1331W
26	018-002041-1	LM GUIDE .. RSR9ZM+65LM
27	044-001113-1	SUBSTRATE SUPPORT .. SB6-50
28	028-003338-1	TUBE JOINT .. M-5HL-4
29	028-001387-1	TUBE JOINT .. EUC4-NI
30	026-100991-1	GROMMET .. C-30-NG-79-C
31	1985-412878-1*	COVER SLIDER ASSY HP
32	1310-496867-14	EXH.BOX
33	1310-496869-12	PACKING
34	1910-320217-14	SLIDER (U-R)
35	1910-320218-14	SLIDER (U-L)
36	1904-400057-11	PIPE GUIDE
37	1310-392236-15	THERMAL INSULATING PLATE A
38	1910-327177-11	SHUTTER SEAL
39	1385-391229-1*	HP SUPPORT ASSY
40	1310-290727-16	SUPPORT RING
41	1903-290727-11	PLATE SUPPORT
42	1310-392239-14	REAR PLATE
43	027-101006-1	O-RING .. VITON AS568-273 BLACK
44	1385-3912200-1*	PIN ASSY (HP,COOL)
45	1910-426349-13	PIN (67)
46	1903-400101-11	PINS STAND BASE
47	1310-496571-15	COVER SUPPORT (A)
48	021-000313-1	CS-RING .. CSTW-3 SUS
49	1385-391308-1*	SHUTTER ASSY (HP,DHP)

50	1310-290999-11	SHUTTER RING (F)
51	1310-290803-12	INNER SHUTTER (H.P)
52	1386-443765-1*	HP PLATE ASSY
53	1381-643695-11	PLATE CONN BOARD ASS'Y
54	1386-443772-14	PIN UP/DOWN SENSOR ASS`Y
55	1386-443774-11	COVER SET SENSOR ASS`Y
56	1386-444607-14	SHUTTER UP/DOWN SENSOR ASS`Y
57	1985-419739-1*	PROXIMITY C-RING TYPE 0.1
58	1310-497583-12	SPACER (0.1)
59	1310-498062-11	SPACER RETAINER (1-S)
60	910-413568-2	GAP PIN (0.1) WITH STEPS
61	020-001727-1	FLAT HEAD SCREW .. M2x3 CLASS 1
62	021-000340-1	C RING FOR HOLE .. RTW-6 SUS304
63	1985-415636-1*	HP COVER ASSY
64	1910-213351-11	EXH. CHAMBER (STD)
65	1910-214032-11	C. COVER (HP)
66	1910-321266-11	C. COVER (T)
67	1910-424104-11	COVER TOP (HP)
68	1910-425550-11	ADJUSTMENT BLOCK ®
69	1910-425551-11	ADJUSTMENT BLOCK (L)
70	1310-496864-12	COVER DAMPER
71	1910-424120-11	DAMPER RETAINER ®
72	1310-496866-13	DAMPER RETAINER (L)
73	1910-423733-11	EXT PIPE (A)
74	1910-423734-11	EXT PIPE (B)
75	026-101708-1	GRIP .. AP-67-BLACK
76	027-101507-1	O-RING .. NITRIL S-6 BLACK
77	1910-320460-11	SLIDER (C-R)
78	1910-320461-11	SLIDER (C-L)
79	044-001094-1	SUBSTRATE SUPPORT .. SB6-21
80	028-002960-1	TUBE JOINT .. M-5P
81	036-100504-1	MAGNET SENSOR .. RS-901M
82	1310-496860-12	SPACE RING
83	1310-392575-11	SEAL RING (T-2)
84	1310-497244-11	C.SPACER
85	1910-425552-12	SLIDER (HP)
86	1910-423414-11	PIPE GUIDE
87	1910-451274-11	STOPPER
88	026-000912-1	FASTENER .. C-522-2-5

TEL Clean Track Mark 7 and Mark 8

DHP Unit

No.	OEM Part No	Parts Name
1	1910-110864-19	MAIN BLOCK
2	1903-200023-13	EXHAUST SUPPORT (HP-L)
3	1903-200022-13	EXHAUST SUPPORT (HP-R)
4	1910-321236-12	EXHAUST BOX (DHP)
5	1310-496574-15	S COVER A
6	1310-496575-13	S COVER B
7	1310-496576-13	S BOLT
8	1904-300090-11	SHUTTER ARM (A-2)
9	1904-300089-11	3 PIN ARM (A-2)
10	1904-400091-11	EXHAUST INTERRUPTER
11	1910-422803-12	DAMPER
12	1910-422804-11	ROD
13	1910-320627-12	UNDER COVER
14	1903-400102-11	3 PIN ARM
15	1903-300013-14	3 PIN ARM © WORKING DRAWING
16	1903-300153-12	SHUTTER ARM (A-2)
17	1310-496582-14	P BLOCK
18	1310-290722-16	HT COVER
19	1904-400087-11	POSITION BRACKET
20	1310-290723-14	BRACKET COVER
21	1310-496603-13	GUIDE PIN
22	1310-497102-13	COVER SUPPORT (B, DHP)
23	024-015109-1	AIR CYLINDER .. JDAS20*20-1331W
24	024-015110-1	AIR CYLINDER .. JDAS20*25-1331W
25	018-001361-1	LM GUIDE .. RSR9KME+65LM
26	044-001113-1	SUBSTRATE SUPPORT .. SB6-50
27	028-003338-1	TUBE JOINT .. M-5HL-4
28	026-100991-1	GROMMET .. C-30-NG-79-C
29	1310-497650-11	B. THERMAL INSULATING PLATE
30	1310-497645-11	S. THERMAL INSULATING PLATE (1)
31	1310-497646-11	S. THERMAL INSULATING PLATE (2)
32	028-003337-1	TUBE JOINT .. M-5H-4
33	028-005990-1	TUBE JOINT .. DF-SUS
34	028-008412-1	JOINT PART .. IN-233-463 GASKET
35	1985-412879-1*	COVER SLIDER ASSY DHP
36	1310-496867-14	EXH.BOX
37	1310-496869-12	PACKING
38	1910-320217-14	SLIDER (U-R)
39	1910-320218-14	SLIDER (U-L)
40	1310-497105-12	PIPE GUIDE (DHP)
41	1310-496641-12	BLIND PLATE
42	1310-392571-13	THERMAL INSULATING PLATE (A-2)
43	1985-433207-1*	DHP SUPPORT ASSY
44	1903-300152-11	PLATE SUPPORT
45	1310-392239-14	REAR PLATE
46	1385-391336-1*	PIN ASSY DHP
47	310-494836-1	PIN 8H
48	1903-400101-11	PIN STAND BASE
49	1310-496571-15	COVER SUPPORT (A)
50	1910-445297-12	CLAMP BLOCK

51	1380-001878-12	DHP PLATE .. 8C8HP-HAOV-F
52	310-490349-1	SPACER (10x3)
53	1385-391308-1*	SHUTTER ASSY HP,DHP
54	1310-290999-11	SHUTTER RING (F)
55	1310-290803-12	INNER SHUTTER (H.P)
56	1985-419739-1*	PROXIMITY C-RING TYPE 0.1
57	1310-497583-12	SPACER (0.1)
58	1310-498062-11	SPACER RETAINER (1-S)
59	910-413568-2	GAP PIN (0.1) WITH STEPS
60	020-001727-1	FLAT HEAD SCREW .. M2x3 CLASS 1
61	021-000340-1	C-RING FOR HOLE .. RTW-6 SUS304
62	1985-415675-1*	DHP COVER ASSY
63	1910-214037-11	EXH. CHAMBER (DHP)
64	1910-214043-12	C. COVER (DHP)
65	1910-320458-11	TOP COVER (DHP-P)
66	1910-320459-12	EXT. PIPE (HP-P)
67	1310-497171-11	EXT. PIPE (PIQ)
68	1310-497170-11	COVER TOP (PIQ)
69	1910-424257-11	C.C. BLOCK
70	1910-423734-11	EXT PIPE (B)
71	1910-423414-11	PIPE GUIDE
72	1910-424258-11	THERMAL INSULATING SPACER
73	1910-320460-11	SLIDER (C-R)
74	1910-320461-11	SLIDER (C-L)
75	1910-424259-13	SLIDER (DHP-P)
76	1910-451274-11	STOPPER
77	1910-443599-11	BLOCK
78	1310-496960-11	DAMPER SHAFT
79	1310-496958-11	DAMPER
80	910-413769-1	KNOB
81	1310-496959-13	CLAMP
82	028-002960-1	TUBE JOINT .. M-5P
83	1310-497033-12	SPACE RING
84	026-000912-1	FASTENER .. C-522-2-5
85	1910-425577-11	SPACER (DHP)
86	036-100504-1	MAGNET SENSOR .. RS-901M
87	044-001094-1	SUBSTRATE SUPPORT .. SB6-21
88	1910-444464-11	SPACER
89	1910-445750-11	SPACER
90	026-002709-1	GRIP .. A-67
91	1985-316362-1*	DHP EXH PIPE ASSY (4-2)
92	1310-290871-12	MAIN PIPE (DHP4)
93	1310-392460-14	MAIN PIPE (2)
94	1310-496962-12	STOPPER
95	1310-497038-11	EXH BLIND
96	1310-496963-12	PIPE BRACKET (2)
97	1310-496964-13	PIPE JOINT (2)
98	028-002060-1	TUBE JOINT .. M-5P
99	1985-316361-1*	DHP EXH PIPE ASSY (4-1)
100	1310-290871-12	MAIN PIPE (DHP4)
101	1310-392460-14	MAIN PIPE (2)
102	1310-496962-12	STOPPER
103	1310-497038-11	EXH BLIND
104	1310-496963-12	PIPE BRACKET (2)

105	1310-496964-13	PIPE JOINT (2)
106	028-002960-1	TUBE JOINT .. M-5P
107	1985-316339-1*	DHP EXH PIPE ASSY (1)
108	1910-317970-12	MAIN PIPE (DHP1)
109	1310-392460-14	MAIN PIPE (2)
110	1310-496962-12	STOPPER
111	1910-421447-11	PIPE BRACKET (LH)
112	1310-496964-13	PIPE JOINT (2)
113	028-002960-1	TUBE JOINT .. M-5P
114	1985-316338-1*	DHP EXH PIPE ASSY (2-1)
115	1310-290885-12	MAIN PIPE (DHP 2)
116	1310-392460-14	MAIN PIPE (2)
117	1310-496962-12	STOPPER
118	1310-497038-11	EXH BLIND
119	1310-496963-12	PIPE BRACKET (2)
120	1310-496964-13	PIPE JOINT (2)
121	028-002960-1	TUBE JOINT .. M-5P
122	1985-316337-1*	DHP EXH PIPE ASSY (3-1)
123	1310-290884-12	MAIN PIPE (DHP 3)
124	1310-392460-14	MAIN PIPE (2)
125	1310-496962-12	STOPPER*
126	1310-497038-11	EXH BLIND
127	1310-496963-12	PIPE BRACKET (2)
128	1310-496964-13	PIPD JOINT (2)
129	028-002960-1	TUBE JOINT .. M-5P
130	1985-416661-1*	PIQ COVER ASSY STD-R
131	1910-213351-11	EXH. CHAMBER (STD)
132	1910-213166-11	C. COVER (PIQ)
133	1910-321601-11	TOP COVER (PIQ)
134	1910-321602-11	EXT. PIPE ®
135	1310-497171-11	EXT. PIPE (PIQ)
136	1310-497170-11	COVER TOP (PIQ)
137	1910-426067-11	ARM BLOCK
138	1910-424258-11	THERMAL INSULATING SPACER
139	1910-320460-11	SLIDER (C-R)
140	1910-320461-11	SLIDER (C-L)
141	1910-425552-12	SLIDER (HP)
142	1910-451274-11	STOPPER
143	1910-424261-12	PIPE ENT
144	1310-496960-11	DAMPER SHAFT
145	1310-496958-11	DAMPER
146	910-413769-1	KNOB
147	1310-496959-13	CLAMP
148	026-101708-1	GRIP .. AP-67-BLACK
149	028-002960-1	TUBE JOINT .. M-5P
150	1310-496860-12	SPACE RING
151	026-000912-1	FASTENER .. C-522-2-5
152	036-100504-1	MAGNET SENSOR .. RS-901M
153	1310-290767-12	SEAL RING (2)
154	044-001094-1	SUBSTRATE SUPPORT .. SB6-21
155	1985-416662-1*	PIQ COVER ASSY STD-L
156	1910-213351-11	EXH. CHAMBER (STD)
157	1910-214166-11	C. COVER (PIQ)
158	1910-321601-11	TOP COVER (PIQ)

159	1910-320459-12	EXT. PIPE (DHP-P)
160	1310-497171-11	EXT. PIPE (PIQ)
161	1310-497170-11	COVER TOP (PIQ)
162	1910-426067-11	ARM BLOCK
163	1910-424258-11	THERMAL INSULATING SPACER
164	1910-320460-11	SLIDER (C-R)
165	1910-320461-11	SLIDER (C-L)
166	1910-425552-12	SLIDER (HP)
167	1910-451274-11	STOPPER
168	1910-424261-12	PIPE END
169	1310-496960-11	DAMPER SHAFT
170	1310-496958-11	DAMPER SHAFT
171	910-413769-1	KNOB
172	1310-496959-13	CLAMP
173	026-101708-1	GRIP .. AP-67-BLACK
174	028-002960-1	TUBE JOINT .. M-5P
175	1310-496860-12	SPACE RING
176	026-000912-1	FASTENER .. C-522-2-5
177	036-100504-1	MAGNET SENSOR .. RS-901M
178	1310-290767-12	SEAL RING (2)
179	044-001094-1	SUBSTRATE SUPPORT .. SB6-21
180	1985-413224-1*	PIQ EXH. PIPE ASSY (RH-4-2)
181	1910-213629-12	MAIN PIPE (4)
182	1310-392459-14	MAIN PIPE (1)
183	1310-496962-12	STOPPER
184	1310-497038-11	EXH BLIND
185	1310-496963-12	PIPE BRACKET (2)
186	1310-496964-13	PIPE JOINT (2)
187	028-002960-1	TUBE JOINT .. M-5P
188	1985-413226-1*	PIQ EXH. PIPE ASSY (RH-4-1)
189	1910-213629-12	MAIN PIPE (4)
190	1310-392459-14	MAIN PIPE (1)
191	1310-496962-12	STOPPER
192	1310-497038-11	EXH BLIND
193	1310-496963-12	PIPE BRACKET (2)
194	1310-496964-13	PIPE JOINT (2)
195	028-002960-1	TUBE JOINT .. M-5P
196	1985-413227-1*	PIQ EXH. PIPE ASSY (RH-3-1)
197	1910-213630-12	MAIN PIPE (3)
198	1310-392459-14	MAIN PIPE (1)
199	1310-496962-12	STOPPER
200	1310-497038-11	EXH BLIND
201	1310-496963-12	PIPE BRACKET (2)
202	1310-496964-13	PIPE JOINT (2)
203	028-002960-1	TUBE JOINT .. M-5P
204	1985-413225-1*	PIQ EXH. PIPE ASSY (RH-3-2)
205	1910-213630-12	MAIN PIPE (3)
206	1310-382459-14	MAIN PIPE (1)
207	1310-496962-12	STOPPER
208	1310-497038-11	EXH BLIND
209	1310-496963-12	PIPE BRACKET (2)
210	1310-496964-13	PIPE JOINT (2)
211	028-002960-1	TUBE JOINT .. M-5P
212	1985-316392-1*	PIQ EXH. PIPE ASSY (RH-2-2)

213	1310-392461-12	MAIN PIPE (2-2)
214	1310-392459-14	MAIN PIPE (1)
215	1310-496962-12	STOPPER
216	1310-496963-12	PIPE BRACKET (2)
217	1310-496964-13	PIPE JOINT (2)
218	028-002960-1	TUBE JOINT .. M-5P
219	1985-316394-1*	PIQ EXH. PIPE ASSY (RH-1)
220	1910-318170-12	MAIN PIPE (RH-1)
221	1310-392459-14	MAIN PIPE (1)
222	1310-496962-12	STOPPER
223	1910-421448-11	PIPE BRACKET (RH)
224	1310-496964-13	PIPE JOINT (2)
225	028-002960-1	TUBE JOINT .. M-5P
226	1985-316391-1*	PIQ EXH. PIPE ASSY (LH-1)
227	1910-212710-12	MAIN PIPE (1-3)
228	1310-392460-14	MAIN PIPE (2)
229	1310-496962-12	STOPPER
230	1310-496963-12	PIPE BRACKET (2)
231	1310-496964-13	PIPE JOINT (2)
232	028-002960-1	TUBE JOINT .. M-5P
233	1985-316390-1*	PIQ EXH. PIPE ASSY (LH-2-1)
234	1310-290849-12	MAIN PIPE (1-4)
235	1310-392460-14	MAIN PIPE (2)
236	1310-496962-12	STOPPER
237	1310-497038-11	EXH BLIND
238	1310-496963-12	PIPE BRACKET (2)
239	1310-496964-13	PIPE JOINT (2)
240	028-002960-1	TUBE JOINT .. M-5P
241	1985-316389-1*	PIQ EXH. PIPE ASSY (LH-2-2)
242	1310-290849-12	MAIN PIPE (1-4)
243	1310-392460-14	MAIN PIPE (2)
244	1310-496962-12	STOPPER
245	1310-496963-12	PIPE BRACKET (2)
246	1310-496964-13	PIPE JOINT (2)
247	028-002960-1	TUBE JOINT .. M-5P

TEL Clean Track Mark 7 and Mark 8

COOL Unit

No.	OEM Part No	Parts Name
1	1985-449182-1*	UNIT BASE ASSY (COOL)
2	1910-110864-19	MAIN BLOCK
3	1903-200025-13	EXHAUST SUPPPORT (COL-L)
4	1903-200024-13	EXHAUST SUPPPORT (COL-R)
5	1910-320626-13	EXHAUST BOX
6	1310-496574-15	S COVER A
7	1310-496575-13	S COVER B
8	1310-496576-13	S BOLT
9	1903-300179-11	3 PIN ARM
10	1904-400091-11	EXHAUST INTERRUPTER
11	1910-422803-12	DAMPER
12	1910-422804-11	ROD
13	1910-320427-12	UNDER COVER
14	1310-392236-15	THERMAL INSULATING PLATE A
15	1903-400102-11	3 PIN ARM
16	1903-300013-14	3 PIN ARM (C)WORKING DRAWING
17	1310-496582-14	P BLOCK
18	1904-400066-11	P .SPACER
19	1310-290807-14	COOL.P.COVER
20	1310-290877-13	BRACKET COVER (COOL)
21	1310-496603-13	GUIDE PIN
22	1310-497081-13	COVER SUPPORT (B.COL)
23	024-015109-1	AIR CYLINDER ..JDAS20*20-1331W
24	018-002041-1	LM GUIDE ..RSR9ZM+65LM
25	044-001113-1	SUBSTRATE SUPPORT..SB6-50
26	028-003338-1	TUBE JOINT..M-5HL-4
27	028-001387-1	TUBE JOINT..EUC4-NI
28	1904-400087-11	POSITION BRACKET
29	028-002269-1	TUBE JOINT..F900-L-9.52
30	028-003447-1	TUBE JOINT..F900-R-12.7 x 9.52
31	1385-391231-1*	COOL SUPPORT ASSY
32	1310-290730-16	SUPPORT RING (COOL)
33	1310-392240-15	PLATE SUPPORT COOL (A)
34	1310-392241-15	PLATE SUPPORT COOL (B)
35	1904-400093-11	COVER GUIDE
36	1310-392242-15	REAL PLATE (COOL)
37	1310-496894-11	C/W TUBE (1)
38	1310-496895-11	C/W TUBE (2)
39	1385-391200-1*	PIN ASSY (HP,COOL)
40	1910-426349-13	PIN (67)
41	1903-400101-11	PIN STAND BASE
42	1310-496571-15	COVER SUPPORT (A)
43	021-000313-1	CS-RING . CSTW-3 SUS
44	1386-444535-1*	COOL KIT
45	1381-643695-11	PLATE CONN BOARD ASS'Y
46	1386-443772-14	PIN UP/DOWN SENSOR ASS'Y
47	1985-419739-1*	PROXIMITY C-RING TYPE (0.1)
48	1310-497583-12	SPACER (0.1)
49	1310-498062-11	SPACER RETAINER
50	910-413568-2	GAP PIN (0.1) WITH STEPS

51	020-001727-1	FLAT HEAD SCREW .. M2x3 CLASS 1
52	020-000340-1	C-RING FOR HOLE .. RTW-6 SUS304
53	1985-413167-1*	COOL COVER ASSY (STD)
54	1310-290987-14	COOL COVER (SUS)
55	026-101708-1	GRIP .. AP-67-BLACK

TEL Clean Track Mark 7 and Mark 8

AD Unit

No.	OEM Part No	Parts Name
1	1985-464453-1*	UNIT BASE ASSY (AD)
2	1910-110864-19	MAIN BLOCK
3	1903-200113-11	EXHAUST BLOCK
4	1903-200112-11	EXHAUST BLOCK
5	1910-341932-11	EXHAUST BOX
6	1310-496574-15	S COVER A
7	1310-496575-13	S COVER B
8	1310-497080-12	S. BOLT (AD)
9	1310-496576-13	S BOLT
10	1903-300179-11	3 PIN ARM
11	1904-400091-11	EXHAUST INTERRUPTER.. (199880117611
12	1910-422803-12	DAMPER
13	1910-422804-11	ROD
14	1910-320627-12	UNDER COVER
15	1310-392236-15	THERMAL INSULATING PLATE A
16	1903-400102-11	3 PIN ARM
17	1903-300013-14	3 PIN ARM (C)WORKING DRAWING
18	1310-496582-14	P BLOCK
19	1904-400066-11	P. SPACER
20	1310-290723-14	BRACKET COVER
21	1310-496603-13	GUIDE PIN
22	1310-496572-16	COVER SUPPORT (B)
23	018-002041-1	LM GUIDE ..RSR9ZM+65LM
24	1904-400087-11	POSITION BRACKET.. (199880118211
25	024-015109-1	AIR CYLINDER ..JDAS20*20-1331W (199880166911
26	024-015110-1	AIR CYLINDER ..JDAS25*20-1331W (199880166911
27	044-001113-1	SUBSTRATE SUPPORT .. SB6-50
28	024-007025-1	SPEED CONTROLLER .. SC-M5-L-X1 (A3-549070
29	028-001387-1	TUBE JOINT .. EUC4-NI
30	026-100991-1	GROMMET .. C-30-NG-79-C
31	028-003338-1	TUBE JOINT ..M-5HL-4
32	028-003337-1	TUBE JOINT ..M-5H-4
33	028-003338-1	TUBE JOINT ..M-5HL.4
34	1985-415482-1*	AD SUPPORT ASSY
35	1903-300154-12	PLATE SUPPORT LEG
36	027-100770-1	O-RING ..VITON AS566-173 BLACK
37	1310-392239-14	REAL PLATE
38	1910-215693-11	AD SUPPORT
39	028-002258-1	TUBE JOINT ..F900-L-6.35A
40	028-002302-1	TUBE JOINT ..F900-T-6.35
41	028-003353-1	TUBE JOINT ..F900-R-9.52*6.35
42	017-000227-1	TUBE .. NO.9055-PFA L 9.52*7.52
43	1385-391226-1*	PIN ASSY (AD)
44	1910-419491-13	AD STAND BASE
45	1910-355258-11	AD PIN STAND
46	1910-427632-12	AD PIN (40)
47	1910-358844-11	AD FLANGE
48	1910-418356-16	COVER SUPPORT (AD)
49	027-100220-1	O-RING .. VITON R-10 BLACK

50	1910-444854-11	PACKING
51	028-008411-1	TUBE JOINT .. PLUG M5 (IN-233-457)
52	1386-445726-1*	AD PLATE ASSY
53	1381-643695-11	PLATE CONN BOARD ASS'Y
54	1386-443772-14	PIN UP/DOWN SENSOR ASS'Y
55	1386-445724-11	AD COVER SET SENSOR ASS'Y
56	1386-444607-14	SHUTTER UP/DOWN SENSOR ASS'Y
57	1985-419739-1*	PROXIMITY C-RING TYPE (0.1)
58	1310-497583-12	SPACER (0.1)
59	1310-498062-11	SPACER RETAINER (1-S)
60	910-413568-2	GAP PIN (0.1) WITH STEPS
61	020-001727-1	FLAT HEAD SCREW .. M2x3 CLASS 1
62	021-000340-1	C-RING FOR HOLE .. RTW-6 SUS304
63	1380-001879-12	AD PLATE .. 8C8AD-TF-F
64	1385-391236-1*	CONTROLLER BASE ASSY
65	1910-418340-12	POSITION BRACKET (T)
66	1910-316036-13	TOP PLATE
67	1985-464454-1*	AD CHAMBER ASSY
68	1910-213998-11	AD CHAMBER 1
69	1910-316886-15	CHAMBER HOLDER
70	018-002024-1	LINER WAY .. LWLF14C1R70BES218 (199880154011
71	1910-423770-12	GUIDE ARM
72	1910-419339-14	CYLINDER ARM
73	1910-419541-11	SENSOR BRACKET
74	1910-446651-11	CHAMBER HANDLE
75	044-000045-1	SUBSTRATE SUPPORT .. EM-5
76	1910-418345-13	AIR-OPERATED BRACKET
77	1910-418346-11	FILTER BRACKET
78	026-100868-1	KNOB .. A-1176-21
79	012-001007-1	RESIN VALVE .. AMD01-X20 (199880010811
80	024-006917-1	FILTER .. WGFG21K
81	028-002331-1	TUBE JOINT ..F900-6.35SR
82	028-001330-1	TUBE JOINT ..F900-6.35N
83	028-002045-1	RESIN JOINT ..S-ME WSY-1B
84	028-002100-1	RESIN JOINT ..S-UT-W2YB
85	036-100504-1	MAGNET SENSOR ..RS-901M
86	028-003330-1	TUBE JOINT ELB4-M5-NI
87	1310-290880-13	CHAMBER BASE 2
88	1310-392512-12	AD COVER (M)
89	1910-349890-11	BASE STAND
90	1910-349891-11	BASE STAND
91	1310-497084-12	BASE HOLDER
92	1904-300095-11	POSITION BRACKET .. (199880122511
93	1910-448857-11	COVER
94	1910-448858-11	COVER
95	1910-349933-11	COVER
96	1910-352775-11	SHUTTER BRACKET
97	1910-352776-11	SHUTTER
98	1910-450720-11	PLATE
99	1985-454421-1*	AD COVER ASSY(4)
100	1910-112772-11	AD COVER
101	1910-220318-11	AD COVER
102	1310-497657-11	AD. TC. VISUAL PLATE(1)
103	1310-392683-11	AD EXH.PIPE(1)

104	1310-290967-11	AD EXH.PIPE(2)
105	1310-497492-11	AD PIPE JOINT(1)
106	1310-497493-12	AD PIPE JOINT(2)
107	1310-497494-12	AD STOPPER
108	1310-449838-11	AD COMMUTATION BOARD
109	1310-497496-11	AD DAMPER
110	1310-497497-11	AD DAMPER SHAFT
111	910-413769-1	KNOB
112	1310-497498-11	AD PACKING(1)
113	1310-497499-11	AD PACKING(2)
114	1310-392459-14	MAIN PIPE(1)
115	1310-496959-13	CLAMP
116	1310-392720-11	REAR PLATE(UP-1)
117	1310-496603-13	GUIDE PIN
118	1310-497503-11	AD PIPE BRACKET
119	028-002960-1	TUBE JOINT .. M-5P
120	1310-497644-11	NUT PLATE(3)
121	1310-498296-11	BLIND PLATE(AD)
122	1910-444564-11	GUIDE
123	1910-444566-11	GUIDE

TEL Clean Track Mark 7 and Mark 8

Oven Controller Unit

No.	OEM Part No	Parts Name
1	1385-391236-1*	CONTROLLER BASE ASSY
2	1910-212287-14	UNDER BASE PLATE
3	1910-113324-11	UPPER BASE PLATE
4	1910-211986-15	R SIDE PLATE
5	1910-211987-15	L SIDE PLATE
6	1910-316864-13	EXHAUST PLATE
7	1910-316023-11	SLIDE GUIDE A
8	1910-316024-14	SLIDE GUIDE B
9	1910-316026-13	ELEC PANEL(2F-1)
10	1910-316027-13	ELEC PANEL(2F-2)
11	1910-316028-16	MECHA PANEL(3F-1)
12	1910-316865-13	PANEL OCB-F
13	1910-418328-13	SPEED CONTROLLER STAND
14	1910-418329-13	SPEED CONTROLLER PLATE
15	1910-316032-12	BASE DUCT
16	1910-316033-11	DUCT TYPE 60
17	1910-418330-11	DUCT PACKING
18	1910-418331-12	DUCT ADAPTER
19	1910-418332-12	DAMPER CLIP
20	1910-418333-15	SHAFT SUPPORT
21	1910-419517-13	DAMPER PLATE
22	1910-418335-13	DAMPER SHAFT
23	1910-419516-12	SIDE BRACKET
24	1910-352057-11	SIDE COVER
25	1910-418338-12	COVER PIN
26	1910-222635-11	FRONT COVER
27	1910-211989-13	REAR COVER
28	1910-423379-13	TERMINAL BASE BRACKET (K-07)
29	1910-418342-11	ELEC COVER
30	044-001093-1	SUBSTRATE SUPPORT .. SB6-20
31	026-100002-1	MAGNET CATCH .. C-92-2
32	1910-316862-13	UPPER FRONT BAR
33	1910-316863-12	UPPER REAR BAR
34	1910-419515-13	OCB COVER
35	044-001103-1	SUBSTRATE SUPPORT .. SB6-35
36	026-100650-1	WING PLATE .. B-1100-3
37	1910-419823-13	SHAFT SUPPORT 2
38	044-001046-1	SUBSTRATE SUPPORT .. SB6-10
39	020-002002-1	DECORATIVE SCREW .. M3x6
40	1910-212294-13	ELEC PANEL (1F)
41	1910-425149-11	DAMPER STOPPER
42	1910-351293-12	BASE DUCT
43	028-001384-1	TUBE JOINT .. ELB6-PT1/8-NI
44	028-006367-1	TUBE JOINT .. EUT6-NI
45	1985-412705-1*	UNIT BASE ASSY (HP)
46	028-003338-1	TUBE JOINT .. M-5HL-4
47	024-007025-1	SPEED CONTROLLER .. SC-M5-L-X1
48	028-003337-1	TUBE JOINT .. M-5HL-4
49	1985-453306-1*	UNIT BASE ASSY (DHP)
50	028-003338-1	TUBE JOINT .. M-5HL-4

51	024-007025-1	SPEED CONTROLLER .. SC-M5-L-X1
52	028-003337-1	TUBE JOINT .. M-5HL-4
53	1386-444550-1*	BASE 1 ASSY
54	381-642065-4	LINE CONN BOARD ASS'Y
55	1386-443802-12	DC 24V CABLE
56	1386-443787-12	RELAY 8P CABLE
57	1986-419638-11	MANUAL SW ASS'Y
58	1386-445070-12	PIN.SHUTTER SOLENOID EXT CABLE
59	1386-444551-1*	BASE 2 ASSY
60	039-822090-1	DC POWER SUPPLY .. S82J-2224
61	034-001104-1	TERMINAL BASE .. A131-3
62	034-001103-1	TERMINAL BASE .. A119-10
63	034-000315-1	TERMINAL BASE .. A116-8
64	1386-443802-12	DC 24V CABLE (AD,HP,DHP,COOL)
65	1386-444717-12	HEATER EXT CABLE (AD,HP,DHP)
66	1386-444717-12	HEATER EXT CABLE NO.1
67	1386-444718-12	HEATER EXT CABLE NO.2
68	1386-444719-12	HEATER EXT CABLE NO.3
69	1386-444720-12	HEATER EXT CABLE NO.4
70	1386-446191-11	AD HEATER EXT CABLE NO.2
71	1386-446192-11	AD HEATER EXT CABLE NO.3
72	1386-446193-11	AD HEATER EXT CABLE NO.4
73	1386-443787-12	RELAY 8P CABLE (AD,HP,COOL)
74		PIN.SHUTTER-SOLENOID CABLE NO.1~40
75	1386-444705-12	PLATE SENSOR CABLE NO.1
76	1386-444706-12	PLATE SENSOR CABLE NO.2
77	1386-444707-12	PLATE SENSOR CABLE NO.3
78	1386-444708-12	PLATE SENSOR CABLE NO.4
79	1386-446185-11	AD PLATE SENSOR CABLE NO.2
80	1386-446186-11	AD PLATE SENSOR CABLE NO.3
81	1386-446187-11	AD PLATE SENSOR CABLE NO.4
82	1386-443786-11	HMDS CONT CABLE (AD)
83	1386-443785-13	AD-SOLENOID CABLE
84	1386-409964-12	JPT EXT CABLE NO.1
85	1386-409965-12	JPT EXT CABLE NO.2
86	1386-409966-12	JPT EXT CABLE NO.3
87	1386-409967-12	JPT EXT CABLE NO.4
88	1993-809969-12	AD JPT EXT CABLE NO.2
89	1993-809970-12	AD JPT EXT CABLE NO.3
90	1993-809971-12	AD JPT EXT CABLE NO.4
91	1386-444547-1*	HP BASE SUB ASSY
92	1386-444543-12	SSR ASS'Y
93	1386-444545-11	CT ASS'Y
94	031-000916-1	CIRCUIT PROTECTOR .. NRLR2100-10AAA-B
95	1386-444790-1*	DHP BASE SUB ASSY
96	1386-444543-12	SSR ASS'Y
97	1386-444545-11	CT ASS'Y
98	031-000916-1	CIRCUIT PROTECTOR .. NRLR2100-10AAA-B
99	1985-464454-1*	AD CHAMBER ASSY
100	1910-452662-11	SPACER
101	028-003337-1	TUBE JOINT .. M-5H-4
102	028-006353-1	TUBE JOINT .. ELB6-M5-NI
103	028-001384-1	TUBE JOINT .. ELB6-PT1/8-NI
104	024-000899-1	VACUUM GENERATOR .. CV-10HR

105	028-001383-1	TUBE JOINT .. EC6-PT1/8-NI
106	028-002258-1	TUBE JOINT .. F900-L-6.35A
107	028-003338-1	TUBE JOINT .. M-5HL-4
108	012-001007-1	RESIN VALVE .. AMD01-X20 (199880010811
109	012-004987-1	MANIFOLD .. M4SB010=M5-C2-6-FL209 (A3-209897
110	1910-431948-12	AD EXH.BRACKET
111	012-001011-1	RESIN VALVE .. AMD21-X20 (199880010811
112	028-001384-1	TUBE JOINT .. ELB6-PT1/8-NI
113	012-006101-1	RESIN VALVE .. AMD01-X60
114	028-002197-1	TUBE JOINT .. F900-H-6.35A
115	1985-464453-1*	UNIT BASE ASSY (AD)
116	024-007025-1	SPEED CONTROLLER .. SC-M5-L-X1
117	028-003337-1	TUBE JOINT .. M-5H-4
118	028-003338-1	TUBE JOINT .. M-5HL-4
119	1985-449182-1*	UNIT BASE ASSY (COOL)
120	1310-496587-12	POSITIONING BRACKET
121	1310-496603-12	GUIDE PIN
122	028-003338-1	TUBE JOINT .. M-5HL-4
123	024-00702501	SPEED CONTROLLER .. SC-M5-L-X1
124	028-003337-1	TUBE JOINT .. M-5H-4
125	1985-449182-1*	COVER SUPPORT(4)
126	1310-392245-13	FIXING COVER(4A)
127	1310-392246-13	FIXING COVER(4B)

TEL Clean Track Mark 7 and Mark 8

Inter Face Unit

No.	OEM Part No	Parts Name
1	1985-424325-1*	I/F FRAME (R-5) ASSY
2	1910-111290-15	I/F FRAME 2 (R5)
3	1910-318956-11	CASTER BASE
4	026-001293-1	CASTER .. 500R-N 38MM
5	033-000399-1	NUT .. M20 MF-ZNB CLASS 3
6	1910-432115-12	EARTH-PLATE (9)
7	1985-436558-1*	I/F FRAME PARTS ASSY (5-HS2)
8	1910-320531-13	BOTTOM COVER
9	1910-325183-12	COVER REAR PLAE
10	1910-325184-12	WIRING COVER
11	1910-430099-11	WIRING DUKT(1)
12	1910-430100-11	WIRING DUKT(2)
13	1910-430101-11	BLIND PLATE
14	044-001088-1	BOARD SUPPORT .. SB6-15
15	1910-423007-11	SIDE PLATE
16	1910-428545-11	WIRING BRACKET
17	1985-412482-1*	I/F FRAME JOING ASSY (R-2)
18	1910-326432-12	GUIDE RAIL (CAR)
19	1910-326486-11	GUIDE RAIL (P/S)
20	1910-329265-12	STOPPER BLOCK
21	1903-300150-11	LOCATION BLOCK
22	1910-423163-11	POSITIONING DOLLY BLOCK(SPECIAL B)
23	1910-422903-12	JOINT BRACKET
24	1310-496682-12	SPRING CASE
25	1310-496683-12	HEXAGONAL BOLT ADDITIONAL WORK DRAWING
26	1910-423165-11	HOOK
27	1310-496791-11	CHAIN ASSEMBLY
28	021-100309-1	E RING .. ETW-6 SUS304
29	025-100232-1	SPRING .. 1128
30	026-101296-1	KNOB .. SK-38-WHITE
31	1910-423162-11	JOINT BRACKET (SPECIAL)
32	1910-441761-11	BASE
33	1985-414035-1*	I/F FRONT PANEL DOOR ASSY (L)
34	1310-392304-13	FRONT DOOR PANEL (L)
35	385-400683-1	HINGE ASSY
36	310-410545-1	FIXING SHAFT
37	1310-496744-11	M/S ABSORPTION PLATE MOUNTING PLATE (A)
38	026-100422-1	RUBBER LEG .. TK-10-5171
39	1985-417197-1*	I/F MAGNET CATCH ASSY (FRONT)
40	1910-426247-11	BASE PLATE (F)
41	1910-423936-11	ABSORPTION PLATE (F)
42	026-100127-1	MAGNET CATCH .. TL-105S-1202
43	1985-414036-1*	I/F FRONT PANEL DOOR ASSY (R)
44	1310-392305-13	FRONT DOOR PANEL (R)
45	385-400683-1	HINGE ASSY
46	310-410545-1	FIXING SHAFT
47	1310-496744-11	M/C ABSORPTION PLATE MOUNTING PLATE (A)
48	026-100442-1	RUBBER LEG .. TK-10-5171
49	1085-423099-1*	I/F FRONT DOOR ASSY (R-2)

50	310-41054501	FIXING SHAFT
51	1310-392306-17	PANEL SUPPORT (R-1)
52	1310-392307-16	PANEL SUPPORT (R-2)
53	1910-318030-11	SIDE BAR (A)
54	1910-330138-11	SIDE BAR
55	1310-496745-12	HINGE PIN
56	1310-496746-13	SIDE PLATE (1)
57	1310-496747-13	SIDE PLATE (2)
58	1310-496748-11	M/C ABSORPTION PLATE (A)
59	1310-434487-11	MAGNET PLATE
60	021-100140-1	E RING ·· ETW-3 SUS304
61	1910-421236-11	SIDE BAR NUT (A, C)
62	1910-423543-11	SIDE BAR NUT (I/F-B)
63	020-000067-1	CAP SCREW ·· M5x30 MF-ZNB
64	020-002068-1	COUNTERSUNK HEAD SCREW ·· M3x10 MF-ZNB
65	1987-412795-1*	8 IPL DOOR SW ASSY (FR/UPPER)
66	1910-426080-11	SWITCH CLAMP (F-UP)
67	1986-40442-12	DOOR SW 5 ASSY
68	1985-431811-1*	I/F PANEL PARTS ASSY (R)
69	1310-496740-11	HINGE BRACKET (L)
70	1310-496742-11	HINGE BRACKET (R)
71	1910-429806-11	FIXING SHAFT BRACKET (L)
72	1910-429805-11	FIXING SHAFT BRACKET (R)
73	1910-424654-11	PANEL HANGER BRACKET (1)
74	1910-424655-11	PANEL HANGER BRACKET (2)
75	1910-423883-12	BASE PLATE (1)
76	1910-423885-11	ABSORPTION PLATE
77	026-101373-1	CATCH ·· C-105-2
78	026-100398-1	MAGNET CATCH ·· C100-B-2
79	026-100398-1	MAGNET CATCH ·· C-54-1
80	026-100535-1	MAGNET CATCH ·· TL-107-2-1207A
81	1985-414037-1*	I/F SIDE PANEL ASSY (A)
82	1910-212874-11	SIDE PANEL (A)
83	1910-421576-12	PANEL REINFORCING MATERIAL (C)
84	1985-414038-1*	I/F SIDE PANEL ASSY (B)
85	1310-392311-11	SIDE PANEL (B)
86	1310-496758-12	PANEL REINFORCING MATERIAL (D)
87	1985-414043-1*	I/F REAR PANEL DOOR ASSY (R-2)
88	385-400683-1	HINGE ASSY
89	310-410545-1	FIXING SHAFT
90	1310-290769-12	REAR PANEL DOOR (R)
91	1310-496751-12	PANEL REINFORCING MATERIAL (A)
92	1310-496752-12	PANEL REINFORCING MATERIAL (B)
93	1310-496752-13	M/C ABSORPTION PLATE MOUNTING PLATE (B)
94	1310-496754-12	M/C ABSORPTION PLATE MOUNTING PLATE (C)
95	1987-412796-1*	8 IPL DOOR SW ASSY (FR/REAR)
96	1985-433951-1*	I/F TOP COVER ASSY
97	1910-330800-12	FR TOP COVER
98	1910-330801-11	REAR TOP COVER
99	1910-330802-11	SIDE TOP COVER
100	1910-330803-11	SIDE TOP COVER
101	1910-435166-11	SIDE BLOCK
102	1985-316697-1*	FAN UNIT ASSY (R TYPE)
103	1310-392339-12	F/F MOUNTING BRACKET (R-1)

104	1910-318362-12	F/F MOUNTING BRACKET (R-2)
105	1310-496814-12	F/F MOUNTING BRACKET (R-3)
106	1910-318363-12	F/F MOUNTING BRACKET (R-4)
107	1310-392342-12	F/F MOUNTING BRACKET (A)
108	1310-392343-12	F/F MOUNTING BRACKET (B)
109	1310-392344-11	CURRENT PLATE (R-1)
110	1910-318364-11	CURRENT PLATE (R-2)
111	1310-392346-11	CURRENT PLATE (R-3)
112	1910-318365-11	CURRENT PLATE (R-4)
113	1310-392348-11	CURRENT PLATE (A)
114	1310-392349-11	CURRENT PLATE (B)
115	1910-421776-11	BLIND (R)
116	1985-460397-1*	I/F TOP COVER (R-FAN) ASSY
117	1910-214151-11	TOP COVER (R2-1)
118	1910-212876-11	TOP COVER (R-2)
119	1310-392312-12	TOP COVER (R-3)
120	1310-496922-12	FRONT PANEL BRACKET (L)
121	1310-496923-12	FRONT PANEL BRACKET (R)
122	1910-318379-11	TOP COVER (R-4)
123	1986-402595-1*	8 IPL FAN ASSY
124	1386-446727-11	ULPA FAN ALARM CABLE
125	1386-445812-11	AC-100V CABLE
126	1985-414579-1*	I/F BRD BRACKET ASSY
127	1310-496793-12	BRD BRACKET (1)
128	1310-496794-11	BRD BRACKET (2)
129	1910-421960-11	BRD BRACKET (3)
130	1910-423476-11	BRD BRACKET (4)
131	044-000045-1	SUSSTRATE SUPPORT ·· EM-5
132	1986-402596-1*	8 IPL I/F CABLE
133	1386-459741-11	8 PIN UP/D SOL ASSY L1600
134	1986-400166-13	DC SUPPLY CABLE
135	1386-446183-12	FLAT 26P CABLE
136	1386-444343-12	BURNDY 6P-6P CABLE
137	1386-459762-11	8 A/S SENSOR 1 EXT CABLE 1500
138	1386-459763-11	8 A/S SENSOR 2 EXT CABLE 1800
139	386-442665-2	STEPPER I/F CABLE #2
140	1386-444439-11	FLAT CABLE 64P WITH RELAY CONNECTOR
141	1386-444440-12	LED DISPLAY DC CABLE
142	1386-444160-12	STAGE SWITCH CABLE
143	1386-455139-12	DOOR SW EXT CABLE #8
144	1386-448891-12	DOOR SW EXT CABLE #2
145	1386-444344-12	BURNDY 9P-9P CABLE
146	1386-443533-11	FLAT 64S CABLE
147	1386-443946-11	FLAT 34S CABLE
148	1386-445101-12	CARRIER SENSOR EXT CABLE
149	1386-445100-12	CARRIER SENSOR EXT CABLE #2
150	1386-445634-11	IMC CONN CABLE 1
151	1386-445635-11	IMC CONN CABLE 2
152	1386-444342-13	AMP9P-BURNDY 9P CABLE
153	1386-44412-14	EDGE SENSOR LIGHT SOURCE EXT ·· CABLE
154	1386-446741-11	FLAT 64P CABLE
155	1386-446983-13	FLAT CABLE 26P
156	1386-447739-12	SIG EXT CABLE #2
157	1986-408411-11	8PIN U/D SW2 CABLE L1800

158	1985-414467-1*	I/F CABLE FIXATION ARM (R) ASSY
159	1910-320452-11	ARM (R-1)
160	1910-320453-13	ARM (R-2)
161	1910-424243-13	BRACKET (R)
162	1910-424238-11	ABSORPTION PLATE
163	1910-424244-11	STOPPER (R-1)
164	1910-424276-12	STOPPER (R)
165	1910-424241-11	SHAFT
166	1910-424242-11	BUSHING
167	026-100133-1	MAGNET CATCH .. TL-99S-1215
168	021-100293-1	E RING .. ETW-9 SUS304
169	032-000206-1	FLAT WASHER .. M12SUS304 POLISHED ROUND
170	026-001420-1	CASTER .. K-142-8Y
171	1985-430296-1*	I/F UTILITY PANEL (NOR-R) ASSY
172	1910-320491-11	PAN (R)
173	1910-328874-11	UTILITY PANEL RIGHT
174	1910-433500-11	BRACKET
175	1910-433488-12	CLAMP
176	1910-433487-12	CBLOCK
177	1910-424298-11	PILLAR
178	028-0029252-1	PILLAR JOINT .. M-5E
179	1985-414061-1*	I/F UTILITY JOINT ASSY (AIR)
180	028-005178-1	QUICK JOINT .. CA-00FS(NBR)
181	028-006396-1	QUICK JOINT .. CA-00MP FOR EXTERNAL THREAD
182	028-002953-1	THBE JOINT .. M-5G1
183	028-006341-1	THBE JOINT .. EC6-M5-NI
184	1985-429612-1*	COUPLER (SUS) ASSY
185	028-008294-1	QUICK JOINT .. JOINT SVHC06-06F
186	028-008295-1	QUICK JOINT .. JOINT SVHN06-06F
187	028-007304-1	TUBE JOINT .. C1N3/8-PT3/8ST
188	028-005382-1	TUBE JOINT .. C1N1/2-PT3/8ST
189	017-000270-1	POLYURETHANE TUBE .. U2-1-3/8 TRANSPARENT
190	1985-428963-1*	I/F OPE-PANE (R) ASSY
191	1310-290739-13	OPERATION PANEL PLATE (2)
192	1310-392250-14	OPERATION PANEL BACK(2)
193	1904-300029-11	SIDE PLATE 1
194	1904-300030-11	SIDE PLATE 2
195	1310-392252-12	PANEL COVER BASE -R
196	310-493261-1	PANEL SPACER
197	310-493256-1	COVER HINGE PIN
198	026-100140-1	MAGNET CATCH .. TL-98S-1199
199	1985-412114-1*	OPE-PANE ARM PAUSE SW ASSY
200	1910-420434-11	SW BLOCK (K)
201	1910-418578-11	SWITCH BRACKET (1)
202	1986-402594-1*	8 IPL I/F OPEPANE ASSY
203	1386-444345-12	ARM PAUSE SW ASSY
204	1386-463472-11	8 PAUSE SW EXT CABLE L1000
205	1386-459742-11	8 PIN UP SW ASSY L150
206	1386-459743-11	8 PIN UP EXT CABLE L1800
207	1986-408412-11	8 PIN UP/DOWN SW2 ASSY L150
208	1986-408411-11	8 PIN UP/DOWN SW2 CABLE L1800
209	1985-445770-1*	I/F OPE-PANE ASSY (R5-SYS)
210	1910-341092-11	SW PANEL
211	1985-436556-1*	CASSETTE STAGE (8"PU-HS2)

212	1910-218110-13	8" CASSETTE STAGE
213	1910-437483-12	SENSOR PLATE
214	1910-437482-11	SENSOR STAND
215	310-496424-3	SENSOR BLOCK B
216	310-492483-1	SPRING (ELV)
217	1910-420679-12	SNESOR BLOCK
218	1910-400074-11	SHAFT GUIDE (199880105611)
219	1910-422608-11	SENSOR SHAFT (L)
220	044-000044-1	SUBSTRATE SUPPORT .. EM-3
221	021-100011-1	E RING .. 4 SUS304
222	1910-422942-11	SENSOR COVER
223	1985-436559-1*	I/F CASSETTE STAGE PARTS (HS2)
224	1910-424854-11	HOUSING (R-LD)
225	1910-437503-11	PLATE
226	1910-425154-11	FLOORPLATE (R)
227	1985-436569-1*	I/F 8" CARRIER GUIDE (P/U-HS2)
228	1904-300073-11	CASSETTE CENTER GUIDE
229	1904-400035-11	CASSETTE GUIDE 80M (R)
230	1910-424846-12	NUT PLATE (CARRIER GUIDE)
231	1910-437485-11	CARRIER SPACER
232	1904-400036-11	CASSETTE GUIDE 80M (L)
233	1986-401984-1*	8 CASSETTE STAGE ASSY #1
234	1386-444163-13	WAF EDGE SENSOR LIGHT SOURCE
235	1386-444165-14	WAF EDGE SENSOR RECIVER
236	1386-445099-13	CARRIER SENSOR BOARD ASSY
237	1985-418207-1*	I/F CASSETTE STAGE (8"BUF-LOW) ASSY
238	1910-214386-12	CASSETTE STATE (8"S)
239	310-496424-3	SENSOR BLOCK B
240	310-492483-1	SPRING (ELV)
241	1910-420679-12	SENSOR BLOCK B
242	1910-400074-11	SHAFT GUIDE
243	1910-422608-11	SENSOR SHAFT (L)
244	044-000044-1	SUBSTRATE SUPPORT .. EM-3
245	021-100011-1	E RING .. 4 SUS304
246	1910-422942-11	SENSOR COVER
247	1985-418206-1*	I/F CASSETTE STAGE(8"BUF-UP) ASSY
248	1910-214323-12	CASSETTE STAGE (8")
249	1310-496551-14	SENSOR MOUNTING PLATE
250	1310-496552-12	SENSOR MOUNTING STAND
251	310-496424-3	SENSOR BLOCK B
252	310-492483-1	SPRING (ELV)
253	1910-420679-12	SENSOR BLOCK
254	1904-400074-11	SHAFT GUIDE
255	1910-422608-11	SENSOR SHAFT (L)
256	044-000044-1	SUBSTRATE SUPPORT .. EM-3
257	021-100011-1	E RING .. 4 SUS304
258	1910-422942-11	SENSOR COVER
259	1985-413229-1*	ALUMINIUM CARRIER GUIDE ASSY
260	1910-421185-11	GUIDE (F)
261	1910-421186-11	GUIDE (R)
262	1910-421187-11	GUIDE (L)
263	1910-424846-12	NUT PLATE (CARRIER GUIDE)
264	1910-300073-11	CASSETTE CENTER GUIDE
265	1910-424147-11	CARRIER SPACER (F.R)

266	1986-401985-1*	8 CASSETTE STAGE ASSY #2
267	1386-444163-13	WAF EDGE SENSOR LIGHT SOURCE
268	1386-444165-14	WAF EDGE SENSOR RECEIVER
269	1386-445099-13	CARRIER SENSOR BOARD ASSY
270	1985-436556-1*	CASSETTE STAGE (8"PU-HS2)
271	1910-218110-13	8" CASSETTE STAGE
272	1910-437483-12	SENSOR PLATE
273	1910-437482-11	SENSOR STAND
274	310-496424-3	SENSOR BLOCK B
275	310-492483-1	SPRING (ELV)
276	1910-420679-12	SNESOR BLOCK
277	1910-400074-11	SHAFT GUIDE
278	1910-422608-11	SENSOR SHAFT (L)
279	044-000044-1	SUBSTRATE SUPPORT .. EM-3
280	021-100011-1	E RING .. 4 SUS304
281	1910-422942-11	SENSOR COVER
282	1985-436559-1*	I/F CASSETTE STAGE PARTS (HS2)
283	1910-424854-11	HOUSING (R-LD)
284	1910-437503-11	PLATE
285	1910-425154-11	FLOORPLATE (R)
286	1985-436569-1*	I/F 8" CARRIER GUIDE (P/U-HS2)
287	1904-300073-11	CASSETTE CENTER GUIDE
288	1904-400035-11	CASSETTE GUIDE 80M (R)
289	1910-424846-12	NUT PLATE (CARRIER GUIDE)
290	1910-437485-11	CARRIER SPACER
291	1904-400036-11	CASSETTE GUIDE 80M (L)
292	1986-401984-1*	8 CASSETTE STAGE ASSY #1
293	1386-444163-13	WAF EDGE SENSOR LIGHT SOURCE
294	1386-444165-14	WAF EDGE SENSOR RECIVER
295	1386-445099-13	CARRIER SENSOR BOARD ASSY
296	1985-418207-1*	I/F CASSETTE STAGE (8"BUF-LOW) ASSY
297	1910-214386-12	CASSETTE STATE (8"S)
298	310-496424-3	SENSOR BLOCK B
299	310-492483-1	SPRING (ELV)
300	1910-420679-12	SENSOR BLOCK B
301	1910-400074-11	SHAFT GUIDE
302	1910-422608-11	SENSOR SHAFT (L)
303	044-000044-1	SUBSTRATE SUPPORT .. EM-3
304	021-100011-1	E RING .. 4 SUS304
305	1910-422942-11	SENSOR COVER
306	1985-418206-1*	I/F CASSETTE STAGE(8"BUF-UP) ASSY
307	1910-214323-12	CASSETTE STAGE (8")
308	1310-496551-14	SENSOR MOUNTING PLATE
309	1310-496552-12	SENSOR MOUNTING STAND
310	310-496424-3	SENSOR BLOCK B
311	310-492483-1	SPRING (ELV)
312	1910-420679-12	SENSOR BLOCK
313	1904-400074-11	SHAFT GUIDE
314	1910-422608-11	SENSOR SHAFT (L)
315	044-000044-1	SUBSTRATE SUPPORT .. EM-3
316	021-100011-1	E RING .. 4 SUS304
317	1910-422942-11	SENSOR COVER
318	1985-413229-1*	ALUMINIUM CARRIER GUIDE ASSY
319	1910-421185-11	GUIDE (F)

320	1910-421186-11	GUIDE (R)
321	1910-421187-11	GUIDE (L)
322	1910-424846-12	NUT PLATE (CARRIER GUIDE)
323	1910-300073-11	CASSETTE CENTER GUIDE
324	1910-424147-11	CARRIER SPACER (F.R)
325	1986-401985-1*	WAFER STAGE ASSY
326	1386-444163-13	WAF EDGE SENSOR LIGHT SOURCE
327	1386-444165-14	WAF EDGE SENSOR RECEIVER
328	1386-445099-13	CARRIER SENSOR BOARD ASSY
329	1985-414101*	I/F WAFER STAGE ASSY(NSR-2)
330	1910-213578-13	WAFER STAGE
331	1910-216673-11	FRONT STAGE
332	1910-216674-11	REAR STAGE
333	1910-421653-11	REAR PLATE
334	1910-421654-12	SIDE BRACKET ®
335	1910-421655-12	SIDE BRACKET(L)
336	1910-423138-11	PIN
337	1910-422126-13	PIN CAP
338	1985-424626-1*	I/F STAGE FRAME ASSY(3)
339	1380-000692-11	MODULE FRAME
340	1910-429860-11	JOINT
341	033-000147-1	T NUT .. L5-TST 4
342	1986-402596-1*	8 IPL I/F CABLE
343	1987-419585-11	WAFER STAGE SENSOR ASSY
344	1985-414102-1*	I/F WAFER STAGE ASSY(FPA-2)
345	1910-213577-12	WAFER STAGE
346	1910-320574-11	BASE
347	1910-318299-11	REAR PLATE
348	1910-318303-12	SIDE BRACKET (R)
349	1910-318304-12	SIDE BRACKET (L)
350	1910-421652-12	REINFORCING BAR
351	1910-423138-11	PIN
352	1910-422126-13	PIN CAP
353	1910-433762-11	NUT PLATE
354	1910-424406-11	REINFORCING BRACKET
355	033-000147-1	T NUT .. L5-TST 4
356	1380-00113-11	CLEAN AIR TABOT WEAR ARM CR1172W-D
357	1380-00114-11	CLEAN AIR TABOT WEAR ARM CR1173W-D
358	1380-00115-11	CLEAN AIR TABOT WEAR ARM CR1174W-D
359	0380-001293-11	CLEAN AIR TABOT IN CR 1329W-D
360	0380-001294-11	CLEAN AIR TABOT IN CR 1330W-D
361	0380-001295-11	CLEAN AIR TABOT IN CR 1331W-D
362	1380-001296-11	CLEAN AIR TABOT BOWN CR 1332W-D
363	1386-453642-11	TABOT ARM1 UP/DOWN SENSOR
364	1386-453643-11	TABOT ARM1 IN/OUT SENSOR
365	1386-453644-11	TABOT ARM2 UP/DOWN SENSOR
366	1386-453645-11	TABOT ARM2 IN/OUT SENSOR
367	1986-402596-1*	8 IPL I/F CABLE
368	1987-419585-11	WAFER STAGE SENSOR ASSY
369	1985-421375-1*	I/F 8" CONVERSION KIT(FPA)
370	1910-318301-12	WAFER GUIDE (8" . S)
371	1910-318302-12	WAFER GUIDE (8" . L)
372	021-000340-1	C RING FOR HOLE .. RTW-6 SUS 304
373	910-413568-2	GAP PIN (0.1) WITH STEPS

374	1986-402596-1*	8 IPL I/F CABLE
375	1386-459746-11	8 PIN UP SENSOR ASS'YL200
376	1386-459747-11	8 PIN DOWN SENSOR ASS'Y L200
377	1985-424492-1*	I/F EXT STAGE ASSY(R)
378	1910-325110-11	EXT STAGE BASE
379	1910-325112-11	CYLINDER PLATE
380	1910-325113-11	STAGE PLATE
381	1910-324272-11	PIN PLATE
382	1910-325114-11	PIN COVER
383	1910-325116-11	CYLINDER COVER
384	1910-430096-11	HOLDER
385	1910-430845-12	PIN
386	1910-430097-11	OBSERVATION WINDOW
387	1910-430136-11	WIRING BRACKET
388	024-010709-1	AIR CYLINDER .. MGQL 12-20-Y69A-XB9
389	024-008101-1	SPEEN CONTROLLER
390	028-00337-1	TUBE JOINT .. M-5H-4
391	1986-402596-1*	8 IPL I/F CABLE
392	1381-64573-16	I/F SOL CONN BOARD #2
393	1986-401320-11	8 COL PIN UP SOL 1 ASSY L300
394	1986-401321-11	8 PIN U/D SENSOR CABLE L3350
395	1986-401324-11	8 COL PIN UP SONSOR ASSY L200
396	1986-401325-11	8 COL PIN DOWN SONSOR ASSY L200
397	1986-401319-11	8 COL PIN SOL EXT CABLE L1850
398	1986-408412-11	8 PIN UP/DOWN SW2 ASSY L150
399	1986-408411-11	8 PIN UP/DOWN SW2 CABLE L 180
400	1986-424573-1*	I/F EXT STAGE COVERSONKIT(8")
401	1910-318302-12	WAFER GUIDE (8". I)
402	1987-412619-1*	8 IPL I/F-X(2)
403	1380-101273-11	X BASE
404	1380-101151-11	P BASE
405	1380-101153-11	PULLEY BASE(H)
406	1380-101154-11	PULLEY BASE(E)
407	1380-101155-11	SHAFT(E)
408	1380-101155-11	SHAFT(H)
409	1380-101160-11	SHAFT(M)
410	1380-101161-11	PULLEY(1)
411	1380-101162-11	PULLEY(2)
412	1380-101163-11	PULLEY(30)
413	1380-101274-12	SLIDE BLOCK(I/F)
414	1380-101165-11	BELT CLAMP
415	1380-101136-11	GUIDE STAND
416	1987-410179-12	MK-7,8 MAPPING SENSOR(8")
417	1380-101167-11	MAP CYLINDER BRACKET
418	1380-101168-11	ROD END PLATE
419	1380-101169-11	MOTOR BRACKET
420	1380-101170-11	MOTOR BRACKET(H-6'/8')
421	1380-101171-11	SENSOR FLAG(X)
422	1380-101172-12	SENSOR BRACKET(MAP)
423	1380-101173-11	SENSOR FLAG(MAP)
424	1380-101177-11	RODEND SPACER
425	1380-101178-11	SPEEN CONTROLLER SPACER
426	1380-101179-11	WIRE CLAMP BASE
427	1380-101275-11	UNDER COVER(3)

428	1380-101276-11	UNDER COVER(4)
429	1380-101186-11	COVER MOUNTING BR
430	024-011601-1	AIR CYLINDER .. 7Z-1 SD6N50P
431	024-007025-1	SPEED CONTROLLER .. SC-M5-F-X1(A3-549070)
432	1380-101187-11	SUBSTRAGE SPACER
433	1380-100526-11	SUBSTRAGE SPACER EP-3
434	018-001786-1	LM GUIDE .. RSR7M+94LM
435	018-001258-1	LINEAR WAY .. LWL7C1R260T1H
436	023-000049-1	TIMING BELT .. 530-2GT-6
437	023-000365-1	TIMING BELT .. 186-2GT-9
438	022-000421-1	BEARING .. LF-1260ZZ
439	021-100011-1	E RING .. S SUS304
440	028-003338-1	TUBE JOINT .. M-5HL-4
441	028-003337-1	TUBE JOINT .. M-5H-4
442	1380-101335-11	I/F X MOTOR ASS'Y
443	1381-644946-13	SENSOR BOARD C ASS'Y
444	036-100573-1	SENSOR FIBER .. E32-T14L
445	1380-101177-11	AMPLIFIER
446	036-000301-1	PHOTOELECTRIC SWITCH AMPLIFIER .. E3X-A11
447	1381-644946-14	SENSOR BOARD C ASS'Y
448	1380-101187-11	SUBSTRATE SPACER .. EP-5
449	1985-417056-1*	I/F 8" CONVERSION KIT(3)
450	310-290647-7	PIN SEN
451	310-392002-8	P HOLDER
452	1910-321310-13	GUIDE(L)
453	1910-321311-13	GUIDE(R)
454	1910-319383-12	COVER(X-1)
455	1910-319384-12	COVER(X-2)
456	1910-321309-11	COVER(X-3)
457	1910-214053-11	COVER(X-4)
458	1910-425613-12	SENSOR BLOCK (SE)
459	1910-425614-12	SENSOR BLOCK (RE)
460	1910-425603-11	SENSOR BRACKET(I/F-8E)
461	1987-415109-1*	8 IPL I/F-Y(R-HS)
462	1380-102241-11	FRAME .. T9512Z02307
463	1380-100593-11	PLATE A
464	1380-100496-11	SIDE COVER R
465	1380-100497-11	MOUNTING HOOK
466	1380-100498-11	ANGLE RETAINER
467	1380-102237-11	SLIDER Y AXIS .. T9512Z02306
468	1380-100501-11	BELT RETAINER
469	1380-102236-11	MOTOR HOUSING .. T9413Z01307
470	1380-101278-11	TOP SIDE COVER
471	1380-100504-11	SIDE COVER(L)
472	1380-100529-11	MOTOR COVER(R)
473	1380-101279-11	MOUNTING ANGLE
474	1380-001870-11	IF-Y MOTOR ASSY .. T9512Z02205
475	1380-001868-12	PULLEY ASSY (1) .. T9512Z02203
476	1380-001869-11	PULLEY ASSY (2) .. T9512Z02204
477	1380-101194-11	PULLEY C
478	1380-100531-11	GUIDE
479	023-000832-1	TIMING BELT .. 290-2GT-9
480	1380-102244-11	DRIVE BELT .. IF-Y(HS)-31
481	1380-102240-11	SENSOR BRACKET .. T9413Z01311

482	1380-102239-11	SHUTTER .. T9413Z01310
483	1380-102242-11	BACKSIDE COVER .. T334-02326
484	1381-644946-14	SENSOR BOARD C ASS'Y
485	1380-102238-11	BELT ATTACHMENT .. T9413Z01309
486	1380-100522-11	HEXAGONAL POST SQ-17.5
487	1380-100523-11	HEXAGONAL POST SQ-18
488	1380-100524-11	HEXAGONAL POST SQ-21
489	1380-100525-11	HEXAGONAL POST SQ-22
490	1380-100526-11	SUBSTRATE SPACER EP-3
491	1380-100530-11	MOTOR COVER (R)
492	1380-101484-11	STOPPER
493	1987-415110-1*	8 IPL I/F-Z(HS)
494	1380-102219-12	IF Z (HS) 01 KR SLIDER (713ST)
495	1380-102245-12	SLIDER Z-AXIS .. T9512Z03301
496	1380-102243-11	UPPER COVER .. T9413Z02302
497	1380-101212-11	PULLEY E
498	1380-101213-11	PULLEY F
499	1380-101214-11	SENSOR RAIL
500	1380-100621-11	SHUTTER (3)
501	1380-100541-11	AIR BLOCK
502	1380-100544-11	CABLE ROLLER
503	1380-101438-11	BRACKET ARM
504	1380-101216-11	BRACKET
505	1380-101217-11	SUPPORT BRACKET(L)
506	1380-101218-11	SUPPORT BRACKER(R)
507	1380-101219-11	CLAMP ARM (L)
508	1380-101220-11	CLAMP ARM (R)
509	1380-101222-11	CLAMP SHAFT
510	1380-101223-11	WIRING BAR
511	1380-101224-11	CLAMPTIZER
512	1380-001260-11	I/F Z AXIS MOTOR
513	1380-100546-11	BELT 73060x9
514	1381-644946-14	SENSOR BOARD C ASS'Y
515	1380-100547-11	SUBSTRATE SPACER EP-6
516	028-00337-1	TUBE JOINT .. M-5H-4
517	1380-101225-11	JOINT
518	1380-101226-11	CIRCUIT BOARD SUPPORT
519	1380-101227-11	EDGING
520	1380-100551-11	SQUARE NUTE
521	1380-101237-11	UNION CONNECTOR
522	1380-100526-11	SUBSTRATE SPACER EP-3
523	1380-101439-11	MOTOR ADAPTER (CS/IF-Z)
524	1380-101440-11	RELAY BRACKET
525	1380-101144-11	BRACKET CABLE Z-X
526	1380-101143-11	FLAT CABLE CN-Z
527	1380-101467-11	CN-20 CABLE
528	1380-101463-11	LIN21 CABLE
529	1380-101461-11	MECHATRONIC CABLE ASS'Y
530	1380-102486-11	AIR TUBE
531	1380-102540-11	SUB PLATE ASSY .. I/F2(H)-Y
532	1987-412622-1*	8 IPL I/F-THETA(2)
533	1380-101282-12	MOTOR BLOCK
534	1380-101283-11	SHAFT
535	1380-101284-11	COVER A

536	1380-101285-11	COVER B
537	1380-101286-11	BEARING RETAINER
538	1380-101287-12	SENSOR PLATE
539	1380-101288-11	SENSOR PLUG
540	1380-101289-11	PULLEY SMALL
541	1380-101290-11	PULLEY LARGE
542	1380-101291-11	PLATE B
543	1380-101292-11	BRD COVER
544	1380-101293-11	PLATE (H)
545	1380-101294-11	PLATE (V)
546	1380-101295-11	SIDE PLATE(I/F)
547	1380-101296-11	POLE I/F
548	1380-101297-11	FAN COVER
549	1380-101298-11	BRD BRACKET .. (I/F THETA)
550	1380-101299-11	BEARING SPACER
551	1380-101300-11	HEXAGONAL POST
552	1380-101236-11	SUBSTRATE SPACER
553	1380-101187-11	SUBSTRATE SPASCER
554	023-000044-11	TIMING BELT .. 303-3GT-15
555	022-000108-11	BEARING .. 6908ZZ
556	1380-101301-11	C TYPE SNAP RING
557	1380-101302-11	COUNTER WEIGHT
558	1380-101303-11	SPRING PIN
559	1380-100590-11	SUBSTRATE
560	1380-101342-11	FAN ASS'Y
561	1381-644946-14	SENSOR BOARD C ASS'Y
562	040-109090-1	FAN PART .. 109-049C FINGER GUARD
563	1386-444073-15	I/F ARM PARTS LIST
564	1380-101455-12	Y AXIS DRIVER MSD011A1XX
565	1380-101456-12	Z AXIS DRIVER MSD011A1XX
566	012-001314-1	MANIFOLD .. XMF520M-02(V91M07200-0)
567	028-00337-1	TUBE JOINT .. M-5H-4
568	1380-101304-11	JOINT
569	1380-101458-11	BOX PANEL 1 (R)
570	1380-101308-11	BOX PANEL 2 (R)
571	1380-101309-11	AIR BLOCK
572	1380-101310-11	BRACKET FLAT (1)
573	1380-101761-11	CONNECTOR BRACKET
574	1380-101240-11	HEXAGONAL POST
575	1380-100567-11	CIRCUIT BOARD SUPPORT .. TCBS-10N
576	1380-101464-11	LIN22 CABLE
577	1380-101465-11	LIN23 CABLE
578	1380-101459-11	CN-4 CABLE
579	1380-101462-11	LIN 18 CABLE
580	1386-445009-12	SERVO AC CABLE
581	1986-402648-11	I/F DRIVER AC JUMPER CABLE
582	1380-101551-11	CN-5 CABLE
583	1380-101553-11	CN-6 CABLE

TEL Clean Track Mark 7 and Mark 8

WEE Unit

No.	OEM Part No	Parts Name
1	1987-411866-1*	UNIT FRAME ASSY (8")
2	1910-322670-12	FRAME (1)
3	1910-322671-12	FRAME (2)
4	1910-427391-12	(8" E.E) FRAME GUIDE (A)
5	1910-427392-11	(8" E.E) SIDE FRAME (A)
6	1910-426469-12	COVER HOOK
7	310-391792-4	DUCT PIPE (2)
8	1910-424910-11	SIDE FRAME (B)
9	1910-322672-12	FRAME (3)
10	1910-322673-13	FRAME (4)
11	1910-426470-12	FRAME FOOT
12	1910-429875-11	FIXING BLOCK
13	1910-426568-12	SUBSTRATE GUIDE (1)
14	1910-426569-12	SUBSTRATE GUIDE (2)
15	1910-424922-11	FIXING PIN
16	310-495758-1	SPACER
17	310-495759-2	SUBSTRATE STOPPER
18	310-491941-1	ADAPTER
19	310-495681-1	PIPE SPACER
20	1910-429870-11	STUD (40)
21	1910-428039-11	SUBSTRATE COVER
22	1910-427192-12	SIDE FRAME (1)
23	1910-427193-11	SIDE FRAME (2)
24	1910-427194-11	SIDE FRAME (2-1)
25	1910-427195-11	SIDE FRAME (3)
26	1910-427196-11	SIDE FRAME (3-1)
27	1910-427197-12	SIDE FRAME (4)
28	1910-427198-12	FRAME BASE
29	1910-425114-11	S.W FIXING BRACKET
30	1386-451357-11	8" WEE COVER SW ASSY
31	1386-448926-12	WEE X EXT CABLE
32	1985-419460-1*	LAMP BASE ASSY (8")
33	1910-111106-11	(8" E.E) LAMP BASE
34	310-392075-2	DUCT PIPE (1)
35	1910-317987-12	DUCT FRANGE
36	310-496344-1	DAMPER SHAFT
37	310-495684-1	DAMPER PLATE
38	310-495685-2	LOCK UNIT
39	1910-320885-11	GAGE MONITOR BRACKET
40	310-496344-2	DUCT PIPE (3)
41	310-496345-1	PIPE SPACER (1)
42	310-496346-1	PIPE SPACER (2)
43	310-491941-1	ADAPTER
44	310-496402-3	WAF COVER (8")
45	024-015250-1	DIFFRENTIAL MANOMETER .. FR51HV 200D
46	028-001165-1	TUBE JOINT .. BF6
47	1987-411863-1*	X DRIVE ASSY (8")
48	1910-111070-11	X, THETA BASE (8")
49	310-391148-1	ENCODER SLIT (A)
50	1910-426449-13	SLIT HOLDER

51	1910-426450-11	BEARING CASE COVER
52	310-493406-2	BEARING SUPPORTER (A)
53	1910-426451-2	BEARING SUPPORTER (B)
54	310-495446-1	X SHAFT MOTOR BRACKET
55	310-493413-1	SENSOR BRACKET (A)
56	018-001495-1	LM GUIDE .. RSR15VMUUC1E+180LPM2 G10
57	310-493461-1	STOPPER BLOCK
58	310-495447-1	BALL SCREW BRACKET
59	019-000004-1	BALL SCREW .. W1601-178P-C5Z16
60	023-000182-1	CUP RING .. MJC-19-6
61	022-100684-1	BEARING .. 7000ADB
62	022-101642-1	BEARING .. 129
63	022-000018-1	BEARING PART .. FU00SUS FINE U NUT
64	044-001126-1	SUBSTRATE SUPPORT .. SF5.5-10
65	044-001118-1	SUBSTRATE SUPPORT .. SG-5
66	021-100466-1	E RING .. ETW-7 SUS304
67	044-001046-1	SUBSTRATE SUPPORT .. SB6-10
68	1386-450278-12	WEE X DRIVER MOTOR EXT CABLE
69	1386-451348-11	8" WEE FLAT CABLE
70	1386-451349-11	8" THETA ENC CABLE
71	1910-214564-11	(8") LM BLOCK (A)
72	1910-214565-11	(8") LM BLOCK (B)
73	1910-321922-11	BEARING CASE
74	310-390894-5	SHAFT (THETA)
75	1910-434595-12	ENCDR
76	1910-426452-11	SEAL BLOCK
77	1910-426453-11	SEAL BLOCK COVER
78	1910-426450-11	BEARING CASE COVER
79	1910-426449-13	SLIT HOLDER
80	310-493410-1	COLLAR (A)
81	310-493411-1	COLLAR (B)
82	310-495846-1	CABLE BASE
83	310-495448-1	SHUTTER
84	310-493414-1	SENSOR BRACKET (B)
85	1910-426454-11	THETA PLATE
86	1910-426455-11	MOTOR BRACKET
87	1910-426456-11	LM BLOCK SUPPORT
88	023-100960-1	CUP RING .. MJC-19-1/4
89	022-100409-1	BEARING .. 6000ZZ
90	022-000-18-1	BEARING PART .. FU00SUS FINE U NUT
91	040-000003-1	MOTOR PART .. FD035AS
92	028-002954-1	TUBE JOINT .. M-5H-6
93	027-000003-1	SEAL .. AR 103499
94	044-001118-1	SUBSTRATE SUPPORT .. SG-5
95	044-001126-1	SUBSTRATE SUPPORT .. SF5.5-10
96	044-001046-1	SUBSTRATE SUPPORT .. SB6-10
97	1386-451137-11	8" WEE THETA ENC ASSY
98	1987-411865-1*	UTILITY ASSY (8")
99	1910-214983-12	DRIVER BRACKET
100	310-495895-1	SIDE BRACKET
101	1910-426457-11	SPEED CONTROLLER FIXING BLOCK
102	310-495697-1	SPEED CONTROLLER SHAFT
103	1910-428496-11	VAC GAGE BRACKET
104	1910-213860-11	EXH. PIPE

105	310-495681-1	PIPE SPACER
106	1910-430456-11	VAC FILTER BRACKET
107	1910-428497-1	NEEDLE VALVE BRACKET
108	028-002961-1	TUBE JOINT .. M-5T
109	028-002956-1	TUBE JOINT .. M-5J
110	028-003338-1	TUBE JOINT .. M-5HL-4
111	028-003339-1	TUBE JOINT .. M-5HL-6
112	028-002954-1	TUBE JOINT .. M-5H-6
113	028-002963-1	TUBE JOINT .. M-5UN
114	028-003337-1	TUBE JOINT .. M-5H-4
115	028-001384-1	TUBE JOINT .. ELB6-PT1/8-NI
116	012-000086-1	MECHANICAL VALVE .. 3V
117	012-007025-1	NEEDLE VALVE GYX-0006 (A4-132790)
118	024-006915-1	SPEED CONTROLLER .. SC-M5-L-XI (A3-549070)
119	012-000577-1	SOLENOID VALVE .. 10-VV5J339-03-N5-X169
120	024-006915-1	FILTER .. ZXI-F
121	012-004209-1	MECHANICAL VALVE .. 3V-3W
122	1386-452945-11	8" WEE VAC SENSOR ASSY
123	1386-453365-11	8" WEE SOLENOID ASSY
124	1386-456567-12	WEE CHECK SW EXT CABLE
125	1386-450279-13	WEE UV CHECK SW ASSY
126	1987-411862-1*	SUTTER ASSY (8")
127	1910-322754-11	(8" E.E) UNIT SHUTTER
128	310-49345-1	DOWSER
129	310-493452-1	SENSOR BRACKET
130	024-014693-1	AIR CYLINDER .. TBDA10*40
131	028-003337-1	TUBE JOINT .. M-5H-4
132	044-001118-1	SUBSTRATE SUPPORT .. SG-5
133	1386-45135-11	8" WEE SHUTTER U/D SENSOR ASSY
134	1910-321964-11	CCD CABLE
135	1910-426458-11	BOARD BRACKET
136	1910-427315-11	HOLDER BRACKET
137	1910-426460-11	HOLDER SHAFT
138	1910-426528-11	SLIDE BLOCK
139	1910-426461-11	LENS GUIDE
140	1910-424966-12	LENS HOLDER
141	1910-427533-11	COVER
142	310-495404-1	STUD
143	310-493505-1	SPACER (2.5)
144	042-000095-1	LENS .. 01 LPX 157
145	1386-451368-12	8" WEE CCD LD ASSY
146	1381-648798-12	WEE CCD BOARD
147	1386-451367-11	8" WEE CCD SENSOR CABLE
148	1910-215370-12	(8") MAIN PLATE (A)
149	1910-425478-11	FRAME BASE
150	310-495768-2	FIBER BRACKET
151	1910-439570-11	BASE
152	1910-426545-11	RAIL BASE (A)
153	1910-336086-11	GUIDE BASE
154	1910-426546-11	RAIL BASE (C)
155	1910-426547-11	MICROMETER BRACKET (A)
156	310-495774-1	MICROMETER BRACKET (B)
157	310-495775-1	SPRING GUIDE
158	310-495776-1	LOCATING BLOCK

159	310-495778-1	CYLINDER BLOCK
160	1910-427362-13	(8") MAIN PLATE (B)
161	310-496056-2	SENSOR BRACKET (C)
162	025-100509-1	SPRING .. 1082
163	018-001027-1	SLIDE PACK ..MR615+35LE (82004600)
164	051-000016-1	MICROMETER .. MHT2-6.5 (148-203)
165	028-000044-1	TUBE JOINT .. MS5HLH-4
166	025-100047-1	SPRING .. 2101
167	310-493443-1	SPRING RETAINER (2)
168	310-495949-1	SPRING RETAINER (3)
169	024-004036-1	FLOATING JOINT .. JA6-3-050
170	1386-451356-11	8" WEE UV SENSOR SHUTTER ASSY
171	1910-321923-11	BASE
172	1910-322106-11	MAIN PLATE
173	1910-426462-11	ADJUSTMENT PLATE
174	1910-426463-11	SPRING RETAINER
175	310-495618-2	ADJUSTMENT BLOCK
176	1910-426464-11	SLIDE BLOCK
177	1910-426465-11	SLIDE BASE
178	1910-426466-11	GUIDE BAR
179	1910-426705-11	HOLDER
180	1910-426467-11	JIG FLANGE
181	1910-426487-11	HOLDER BRACKET (A)
182	310-495872-1	DIAL GAGE BACKET
183	310-495630-1	ADJUSTMENT BOLT
184	310-495631-1	LOCATING PIN
185	310-495632-1	GAUGE FIXING PIN
186	310-495633-1	LOCK NUT
187	1910-426468-11	HOLDER GUIDE
188	310-495638-1	HOLDER FIXING BOLT
189	1910-427797-12	HOLDER BLOCK
190	051-000290-1	DIAL GAGE ..NO.1003
191	021-100010-1	E RING .. 2 SUS304
192	018-001027-1	SLIDE PACK .. MR615+35LE (82004600-1)
193	018-000979-1	SLIDE PACK .. MR615E+25LE (82004150-1)
194	025-100509-1	SPRING .. 1082
195	027-100269-1	O-RING .. NITRAL 1AP-3 BLACK
196	1985-419461-1*	COVER ASSY (8")
197	1910-322755-11	COVER (A)
198	1910-322756-11	COVER (B)
199	1910-322757-11	SLIDE COVER
200	1910-427364-12	COVER GUIDE
201	026-100002-1	MAGNET CATCH .. C-92-2
202	1910-212800-12	POWER SUPPLY COVER
203	1910-318256-11	POWER SUPPLY BRACKET
204	1910-320196-11	DRIVER BASE (WEE)
205	033-000147-1	T NUT ..LS-TST 4
206	1910-421818-11	WEE DRIVER COVER (SUS)
207	1910-432243-11	STOPPER (100-80)
208	1386-451360-11	8" WEE X DRIVER SIGNAL CABLE
209	1386-451361-11	8" WEE X DRIVER MOTOR CABLE
210	1386-451362-11	8" WEE X DRIVER AC CABLE
211	386-442733-2	EE EXT. BOX AC CABLE
212	1386-451359-11	8" WEE THETA DRIVER MORTOR CABLE

213	1386-451358-11	8" WEE THETA DRIVER SIGNAL CABLE
214	1386-448925-11	WEE THETA DRIVER EXT CABLE
215	1386-450277-13	WEE THETA DRIVER MOTOR EXT CABLE
216	1386-450276-14	WEE DC CABLE
217	1386-451370-12	8" WEE LAMP SIGNAL CABLE
218	1386-451371-11	8" WEE LIGHT SENSOR CABLE
219	1386-451372-11	8" WEE LAMP AC POWER CABLE

JTT TECH PTE LTD

1 Yishun Industrial Street 1 #04-24 A'POSH BizHub Singapore 768160

Tel: (65) 6262 5887

Fax: (65) 6339 1383

Website: www.jtt.sg

Email: jtt@jtt.sg

Company Reg. No: 201701120E GST Reg No.: 20-1701120-E

TEL CLEAN TRACK ACT8 PARTS LISTS

No	Name	Model	Remark	Q'TY
1	GHOST REPEATER		TAB1600	
2	SIGNAL TOWER CONTROLLER	STC-C	2181-020009-12	1
3	SIGNAL TOWER CONTROLLER	STC-I/O	2181-020011-11	1
4	SIGNAL TOWER CONTROLLER	STC-ADAPTER	2193-020052-11	1
5	CONTROLLER PC BOARD CARD	IBX-4101		2
6	SCB BOARD	CU60L524W	03-53770	1
7	AC CONT BOARD	HTE-AC2-A-11	TAB1800	1
8	AC CONT BOARD	HTE-TA3-A-11	TAB1900	1
9	PUMP ADD ON BOARD	HTE-PUM-A-11	TAB1200	2
10	CHEMICAL I/O BOARD	CPC-G225B01A-11	TKB2181	2
11	CHEMICAL I/O BOARD		2981-600536-11	1
12	CHEMICAL I/O BOARD	CPC-T0015A-11	TOB1015	3
13	CPU20-II	BG9-3499		2
14	OVEN I/O BOARD	THE-OVN-C-12	TAB1400	1
15	OVEN CONN BOARD		1381-643544-12	2
16	MULTIPOINT TEMPERATURE CONTROLLER	E5ZD-4H01P-2		1
17	SPINNER I/O BOARD	CPC-C223B01B-11	TKB3160	1
18	SPINNER I/O BOARD	CPC-C223B01A-11	TKB2111	1
19	SPINNER I/O BOARD	AP9E-0488B-11	TKB3160	1
20	CUM BOARD	AP9E-0347A-11	TKB3150	2
21	SPIN UNIT CONN BOARD	기록 없음	381-643196-6	11
22	MOTOR I/O BOARD	AP9E-0318C-12	TKB3100	3
23	PRB PANEL I/O BOARD	THE-PRB-C-12	TAB1100	1
24	PRB PANEL I/O BOARD	THE-PRB-A-11	TAB1100	1
25	MAIN BOARD	220-50010D-001-A	SB01-01	5
26	MAIN BOARD	1187-009402-12	UD1-S258-0	1
27	WEE I/O Board		CT2980-091523-12 working	2
28	DC/DC CONVERTER BOARD	CT2981-600310-12		3
29	FDD EXTENSION BOARD	CT2981-600374-11		2
30	PANASONIC DRIVER ASSEMBLY		MSD261Y22	3
31	YASKAWA SERVO PACK	CACR-02-TE1K		4
32	DC BACKUP POWER MODULE		MSE181D	4
33	CPL UNIT			2
34	LHP UNIT			1
35	ADH UNIT			2
36	8" COAT CUP ASSY			2
37	8" DEV CUP ASSY			2
38	6" COAT CUP ASSY			2
39	6" DEV CUP ASSY			2
40	8" DEV H NOZZLE ASSY			2
41	6" DEV H NOZZLE ASSY			2
42	PR NOZZLE ASSY			3
43	RRC PUMP FT-200-1		FT-200-1	4
44	TEL ACT 8 FFU Fan Filter Unit	2980-091974-11		2
45	ESA NSK TEL ACT Theta Servo Drive	ESA-J2006AF3-20		3
46	RRC PUMP F-T100-2			4
47	SMC THERMO CONT. POWER SUPPLY		INR-244-216U	2
48	REX-B870-CS1B		CT2986-430279-W1	4
49	ADH BUFFER TANK ASSEMBLY			2
50	Main Controller	TYPE#2		2
51	Operation Panel	M3200		1
52	FAN FILTER UNIT			1
53	WEE UNIT	-		2
54	AC POWER BOX			1
55	COAT UNIT ASSY			2